

# EUCHNER

## User Manual



Electronic-Key-Manager  
EKM

EN

© 2004 - 2011 EUCHNER GmbH + Co. KG

Alle Rechte vorbehalten. Kein Teil des Handbuchs darf in irgendeiner Form -Druck, Fotokopie, oder einem anderen Verfahren- ohne unsere schriftliche Genehmigung reproduziert oder unter Verwendung elektronischer Systeme verarbeitet, vervielfältigt oder verbreitet werden.

Alle genannten Marken, Produktnamen, Firmennamen, Warenzeichen oder eingetragene Warenzeichen sind das Eigentum ihrer jeweiligen Besitzer. Einige Namen und Firmenbezeichnungen, die in den Beispielen verwendet werden, sind frei erfunden und dienen nur zur Veranschaulichung. Das vorliegende Dokument sowie die zugehörige Software wurden mit Sorgfalt erstellt und nach dem Stand der Technik auf Korrektheit überprüft. Für Schäden, die sich direkt oder indirekt aus dem Gebrauch des Handbuchs oder der übrigen Programme ergeben, ist EUCHNER GmbH + Co. nur im Falle des Vorsatzes oder der groben Fahrlässigkeit verantwortlich zu machen. Die in diesem Handbuch enthaltenen Informationen und die zugehörigen Programme können ohne besondere Ankündigung zum Zwecke des technischen Fortschritts geändert werden.

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks. While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

**Publisher**

EUCHNER GmbH + Co. KG  
Kohlhammerstraße 16  
D-70771 Leinfelden-Echterdingen  
Telefon: 0711/75 97 - 0  
Telefax: 0711/75 33 16  
www.euchner.de  
mailto: info@euchner.de

**Managing Editor**

*Erwin Schätzle*

**Technical Editor**

*Kirsten Brinks*

**Coverdesign**

*Kirsten Brinks*

*October 2016*

*Printed in Germany*

## Table of contents

<b>Part I</b>	<b>Introduction</b>	<b>7</b>
	1.1 What is the EKM .....	7
	1.2 System overview .....	8
	1.3 System requirements .....	9
	1.4 Demo version .....	9
	1.5 Light version .....	10
	1.6 Single-user version .....	10
	1.7 Full version .....	10
	1.8 Explanation of symbols .....	11
<b>Part II</b>	<b>Getting started</b>	<b>13</b>
	2.1 Starting program .....	13
	2.2 Changing default user .....	14
	2.3 Administring a database .....	15
	2.4 Designing user interface and selecting data source .....	15
	2.5 Applying your work in the EKM Designer .....	17
	2.6 Assigning user rights .....	17
<b>Part III</b>	<b>EKM</b>	<b>19</b>
	3.1 Installation .....	19
	3.1.1 EKM files .....	20
	3.2 Starting program .....	20
	3.3 Quitting program .....	21
	3.4 User interface .....	21
	3.4.1 Main window .....	21
	3.4.2 Menus and toolbars .....	22
	3.4.3 Help .....	23
	3.4.4 Language selection .....	24
	3.5 Reading and writing .....	24
	3.5.1 Reading a key .....	25
	3.5.2 Writing a key .....	26
	3.5.2.1 Data entry .....	27
	3.5.3 Using templates .....	30
	3.5.4 Discarding changes .....	32
	3.6 Database viewer .....	32
	3.6.1 Working with data .....	33
	3.6.2 Changing data in the database viewer .....	34
	3.6.3 Deleting database records in the database viewer .....	35
	3.6.4 Exporting data .....	35
	3.6.4.1 CSV export .....	36
	3.6.4.2 SmartCard export .....	38
	3.6.5 Searching for data .....	41
	3.6.6 Filtering data .....	41
	3.6.7 Moving columns .....	44
	3.6.8 Sorting data .....	44
	3.6.9 Grouping data .....	45
	3.7 Importing data .....	46
	3.8 Key export/import .....	48


- 3.9 Design mode ..... 50
  - 3.9.1 Designing a database ..... 51
    - 3.9.1.1 Properties of the data fields ..... 52
    - 3.9.1.2 Order of the bytes on the key ..... 58
    - 3.9.1.3 Inserting data fields ..... 60
    - 3.9.1.4 Deleting data fields ..... 61
    - 3.9.1.5 Changing data fields ..... 62
  - 3.9.2 Designing the layout ..... 64
    - 3.9.2.1 An overview of the EKM Designer ..... 65
      - 3.9.2.1.1 EKM Designer ..... 66
      - 3.9.2.1.2 Alignment palette ..... 66
    - 3.9.2.2 Form components ..... 67
      - 3.9.2.2.1 General properties ..... 70
      - 3.9.2.2.2 Properties of EKM database components ..... 73
      - 3.9.2.2.3 Properties of EKM standard components ..... 78
    - 3.9.2.3 Inserting form components ..... 81
    - 3.9.2.4 Selecting form components ..... 82
    - 3.9.2.5 Changing form components ..... 83
    - 3.9.2.6 Cutting form components ..... 84
    - 3.9.2.7 Copying form components ..... 84
    - 3.9.2.8 Inserting a form component ..... 84
    - 3.9.2.9 Removing form components ..... 85
    - 3.9.2.10 Moving form components ..... 85
    - 3.9.2.11 Aligning form components ..... 85
    - 3.9.2.12 Increasing and reducing the size of form components ..... 86
    - 3.9.2.13 Undoing actions on the form design ..... 86
    - 3.9.2.14 Redoing actions on the form design ..... 86
  - 3.9.3 Applying your work in the EKM Designer ..... 87
  - 3.9.4 Cancelling your work in the EKM Designer ..... 88
- 3.10 User rights ..... 89
  - 3.10.1 Managing groups ..... 91
    - 3.10.1.1 Adding groups ..... 92
    - 3.10.1.2 Editing groups ..... 92
    - 3.10.1.3 Removing groups ..... 93
    - 3.10.1.4 Copying a group ..... 94
  - 3.10.2 Managing rights ..... 95
    - 3.10.2.1 Rights available ..... 95
    - 3.10.2.2 Assigning rights to a group ..... 96
    - 3.10.2.3 Removing rights from a group ..... 97
  - 3.10.3 Managing users ..... 97
    - 3.10.3.1 Adding users ..... 98
    - 3.10.3.2 Editing users ..... 99
    - 3.10.3.3 Deleting users ..... 100
    - 3.10.3.4 Adding users to a group ..... 100
    - 3.10.3.5 Removing users from a group ..... 101
  - 3.10.4 Loggin on and logging off users ..... 102
  - 3.10.5 Changing password ..... 103
- 3.11 EKS interface ..... 103
- 3.12 Server connection ..... 103
- 3.13 Uninstalling ..... 103

**Part IV EKM server 105**

4.1	Installation .....	105
4.1.1	Installation as an application .....	105
4.1.2	Installation as service .....	106
4.1.3	EKM files .....	107
4.2	Starting the EKM server .....	107
4.3	Stopping the EKM server .....	108
4.4	Uninstalling .....	109
4.4.1	Uninstalling the EKM server as application .....	109
4.4.2	Uninstalling the EKM server as service .....	109
4.5	The server configuration wizard .....	110
4.5.1	Configuration of the server .....	111
4.5.2	Log-Properties .....	112
4.5.3	Logger .....	114
4.5.4	Key-Logger .....	115
4.5.5	Users logged on .....	116
4.5.6	Export functions .....	117
4.6	Update function .....	122
4.6.1	EKM client update .....	122
4.6.2	EKM online help update .....	122
4.7	Data backup .....	123
4.8	User-specific logo .....	124
<b>Part V</b>	<b>EKM-Admin</b> .....	<b>126</b>
	<b>Index</b> .....	<b>127</b>

# Introduction

**Part**



## 1 Introduction

### 1.1 What is the EKM


The Electronic-Key-Manager EKM is a comprehensive software solution for programming and managing the Electronic-Key-System EKS. The EKS provides access control on PCs and control units in an industrial environment. In comparison to the issue of a password, considerably more responsibility is assigned to the owner of an Electronic-Key. This provides protection against unauthorized access to operating and visualization systems.

In principle EKS comprises two components: an Electronic-Key and the matching Electronic-Key adapter. It is an inductive Ident system. A memory chip and an antenna are built into the Electronic-Key (transponder). The Electronic-Key adapter is a read/write system with integrated evaluation unit and interface.

EKM supplements the EKS with a flexible, customizable software environment.

Your advantages:


- Electronic-Key programming
- Database-based management of the Electronic-Keys
- Display of data and writing of data to the keys using a flexible user interface
- Expansion of the key memory areas with customizable database fields
- Role-based management of access rights



## 1.2 System overview

EKM is based on a client/server architecture comprising the EKM client and the EKM server.

The Database Designer and Layout Designer are intelligent tools that enable you to design the database and user interface and to customize them without the need for specialist knowledge. The role-based user management makes it possible to simply and rapidly structure users into groups and to assign user rights. This aspect includes comprehensive program functions as well as the clarity and editing features of specific form components.



When a key is read, the data read are displayed on the customizable key data form. During this process the data from the key are interpreted and formatted using the format from the form. The data can be changed on the form and transferred to the key using the write function. In parallel to writing to the key, the key data are transferred to the EKM server where they are saved centrally in the key database. You can access the key database and maintain the data for the Electronic-Key with the aid of a database viewer.



## 1.3 System requirements

EKM has the following system requirements (full version):

- Commercial PC from Pentium II
- Operating system Windows XP / Server 2003 / Server 2008 32 Bit / Server 2008 64 Bit / Windows 7 32 Bit / Windows 7 64 Bit / Server 2008 R2
- Internet-Explorer from version 5.0
- A network card with TCP/IP protocol installed
- A serial or USB interface

To read and write Electronic-Keys you will need an EKS Electronic-Key adapter with serial or with USB interface.

EKM can be operated with Electronic-Keys read/write and Electronic-Keys read-only.



## 1.4 Demo version

The demo version of the EKM allows you to test the full version of the product so that you can see for yourself the advantages.

At a glance:

- Functionality of the full version
- Only local EKM client possible
- Limited to 10 weeks runtime
- Data, database and forms prepared can continue to be used with the full version

The demo version has the complete functionality of the full version of the EKM. The runtime of this version is limited to 10 weeks. The demo version has no network support: client and server must be installed on one computer. All data prepared with the demo version can continue to be used with the full version without problems.



The demo version is only allowed to be used for demonstration, test and evaluation purposes.

## 1.5 Light version

The Light version is a functionally limited version based on the single-user version.

There are the following limitations

### a) in the client:

- No access onto the database viewer
- No template functions
- Export / Import for single keys only
- Only local EKM client possible

### b) in the server:

- No access onto the server. No display of the icon in the tray bar. The server gets automatically started by the client.



There is an upgrade possibility to the single-user or full version. New data are stored in the database and become visible after activation.

The TCP/IP protocol is also required for the EKM light version.

## 1.6 Single-user version

The EKM single-user version enables you to use the full functionality of EKM on a local PC drive.

At a glance:

- Functionality of the full version
- The client automatically starts the EKM server
- Only local EKM client possible
- Data, database and forms prepared can continue to be used with the full version

The single-user version has no network support: client and server must be installed on one computer. All data prepared with the single-user version can continue to be used with the full version without problems.



The TCP/IP protocol is also required for the EKM single-user version.

## 1.7 Full version

The EKM full version has a client/server architecture and full network support.

At a glance:

- Includes all documented functions
- Client/server architecture
- Network support
- System requirements cf. "[System requirements](#)"

## 1.8 Explanation of symbols

The following symbols are used in this manual to identify important instructions and useful information:

**Tip!**

This symbol marks tips and tricks.

**Information!**


This symbol marks general important notes.

**Warning!**

This symbol marks instructions that you should perform to avoid the risk of the loss of data. This symbol therefore appears next to notes that you must observe to be able to use the functionality of EKM.

# Getting started

**Part**




## 2 Getting started

The "Getting started" chapter provides examples of the necessary steps that you must take the first time you use EKM before you read or write Electronic-Keys. During this process you will obtain an overview of the basic functions of the program.


### 2.1 Starting program

Start EKM via the entry in the Windows start menu. On the full version, the EKM server has to be started first. Alternatively EKM can be started by double-clicking the file *EKM.exe* respectively *EKMServer.exe*. Enter the connection parameters for the EKM server. Logon as the default user *ekm* using the password *ekm*. The main EKM window opens with an empty form area.



## 2.2 Changing default user

Open the user manager using *Tools -> User*. Change the name and password for the default user by choosing *User* on the *View* tab, marking the user *ekm* and then clicking *Edit* on the *User* tab. The *Edit user* window opens where you can enter the new user data. Assign the user to the *Administrators* user group.




As necessary add new user groups and users and assign the appropriate rights to the individual user groups.



When adding rights, ensure that the Administrators group has all available rights ([cf. "Rights available"](#)). Leave the user manager with *Close* and logon as a user with administrator rights using *File -> Logon*.

## 2.3 Administiring a database

Use *Tools -> Design mode* to change to the design mode. Now click the *Database* button. The *Database Designer* opens.



Add all the required data fields to the database. During this process define the properties of the data field:

- *OnKey* (data are written to the key)
- *Fieldname*
- *Type*
- *StartByte*
- *Length* (if the data field is written to the key)
- *BitNo* (if the data type is Bit)
- *DisplayType* (for the data types Byte, Word, CRC: *Dez* for decimal notation and *Hex* for hexadecimal notation).
- *Unique* (select to prevent duplicate entries)
- *Template* (select to enable field for templates)


The order of the fields displayed in the *Database viewer* is indicated in the *FieldNo* field. The data fields *KEYID* (data type String) and *LOCKED* (data type Bit) are hard programmed and are not visible in the Database Designer. Accept your entries with *OK*. The *Database Designer* is then closed.

## 2.4 Designing user interface and selecting data source

Now click the *Layout* button. The EKM Designer opens. The component bar on the *EKM Database* and *EKM Standard* tabs in the EKM Designer contains various form components:

- EKM database components: form fields that are bound to the key database and display the data read when the keys are edited.
- EKM standard components: fixed form components such as form field names, images, etc.


To insert form components in the key data form, click the component you require on the *component bar*. Then click the form in the position where you want to insert the form component.



You can change components added:

- In the *component inspector* you can enter or select the properties
- You can move a marked component using the mouse.
- The size of a component can be reduced or increased using Shift + left/right arrow key.
- A component can be moved using Ctrl + left/right arrow key.

Design the form and enter the data source for all EKM database components by marking a component and selecting a database field in the component inspector using *DataBinding* -> *DataField*.



Ensure the database component matches the data type for the data field selected (cf. "[Properties of EKM database components](#)").




## 2.5 Applying your work in the EKM Designer



Once you have finished designing the form for the key data, click *Apply* on the toolbar. Layout design is closed and the program then uses the current layout in the general design mode. Click *Apply* on the toolbar again. EKM changes automatically from the design mode to the read and write mode. The form and the database design are transferred to the EKM server and saved using *Apply*. A read right and an edit right are created for all form components. To enable users to view and edit the form fields, the related rights must be assigned to the corresponding groups.

## 2.6 Assigning user rights

Open the user manager using *Tools -> User*. On the *View* tab choose the *Rights* option so that the rights available are displayed in the window on the right.




Assign the rights to the user groups:

-  Allocate the right marked to the user group marked
-  Allocate all rights available to the user group marked

Close the user manager. All authorized users can now read and write keys.

# EKM



**Part**



## 3 EKM

### 3.1 Installation

To install the EKM, start the installation program "Setup.exe". The installation program guides you through the installation of the application and allows you to choose the folder for the installation and the components installed. Please pay attention to the prompts displayed during the installation.



When EKM is started for the first time, it may be necessary to set the parameters for the connection to the EKM server.

## 3.1.1 EKM files


All files created from EKM are stored in the EKM installation path.



When EKM is installed on Windows 7, Windows Server 2008 or Windows Server 2008 R2 and the installation path is 'C:\Program Files\<EKM>', the operation system redirects user specific files to the VirtualStore. The VirtualStore is located under:  
'C:\Users\<User>\AppData\Local\VirtualStore\Program Files\<EKM>'.

## 3.2 Starting program

Start EKM via the entry in the Windows start menu. On the full version, the EKM server has to be started first. Alternatively EKM can be started by double-clicking the file *EKM.exe* respectively *EKMServer.exe*. The first time the program is started, the *Connection parameters EKM-Server* window opens in front of the program splash screen.



Enter the IP address of the EKM server and the port for the server, and accept the values using *OK*. For local operation the IP address *127.0.0.1* can be used. If a connection is not established, please check,

- Whether the EKM server has been started.
- Whether the IP address and the port for the EKM server have been entered correctly.
- Whether the TCP/IP protocol is correctly installed.

Following successful establishment of the connection, the *Logon* window opens. To logon please enter your user name and password. If logon using a key has been activated in your user profile, you can logon by inserting your key in the EKS Electronic-Key adapter. If the key does not authorize you to logon, a corresponding message is displayed in the Logon window. The first time you start the program, logon as the user *ekm* using the password *ekm*.



The EKM main window opens. If necessary, choose a different port for the EKS Electronic-Key adapter (cf. "[EKS interface](#)"). Then open the user manager using *Tools -> User* and change the data for the default user ( cf. "[User rights](#)"), add new groups and users in the user manager, and manage the user rights.

- When the program is quit the connection parameters and the port set for the EKS Electronic-Key adapter are written to the configuration file *ekm.ini*. You will not be prompted to enter the data again when the program is opened; the data will be retrieved from the configuration file.
- For security reasons, do not forget to change the ekm user setup as an administrator when the program is installed.

### 3.3 Quitting program




To quit the EKM, click *Exit* on the *File* menu.

### 3.4 User interface

#### 3.4.1 Main window

The *EKM* window is the main window of the EKM program. It opens when the program is started:



The EKM main window is divided into the following areas:

- ① Menu bar
- ② Toolbar
- ③ Status bar


- ④ Form area      The data allocated to the key are displayed and can be changed in this area. The design of this area can be customized to the user's specific needs in the design mode.

💡 The size of the window can only be changed in the design mode.

### 3.4.2 Menus and toolbars

The menus and the toolbar contain different commands and buttons depending on the mode in which you are working. The content in the read/write mode is shown in the following as an example.

#### Menu bar and toolbar



The functionality on the menus and the toolbar is dependent on the user rights assigned. In the figure shown above, a user with all administrator rights is assumed.

💡 Menus and menu commands have shortcut keys: Press Alt and the letter underlined in the menu name or menu command.


## Status bar




The following information is displayed on the status bar:

- ① EKM server status The icon indicates the status of the connection to the EKM server. If the icon is green, there exists a connection to the EKM server. A red icon indicates that the connection has been interrupted.
- ② Port selection The port selected for the EKS Electronic-Key adapter is displayed in the Port field. You can select a different port from the drop-down list.
- ③ User indication The name of the user logged on is displayed next to the user icon.

## 3.4.3 Help



To open the Help file, click the *Help* command on the *Help* menu. The *EKM* window opens.



In the Help file you can:

- Page through the topics section by section and display topics.
- Search for topics and display topics.
- Add, remove and display favorites.


The following features are available using the buttons on the toolbar:

- Show/hide Shows or hides the navigation bar
- Back Jumps back to the last page
- Forward Jumps forward to the previous page
- Home Jumps to the home page, i.e. the first page

Print	Prints the current topic
Options	<ul style="list-style-type: none"><li>• Hide Tabs</li><li>• Back</li><li>• Forward</li><li>• Home</li><li>• Stop</li><li>• Refresh</li><li>• Internet Options</li><li>• Print</li><li>• Search Highlight On/Off</li></ul>

### 3.4.4 Language selection

You can change between German and English while the program is running.



### 3.5 Reading and writing

To read key data or to write keys, proceed as follows:

- Check the settings for the EKS Electronic-Key adapter using the manual on the EKS (key-specific settings)
- Connect the EKS Electronic-Key adapter to a power source.
- Connect the EKS Electronic-Key adapter to a serial interface or USB interface on your computer.
- Choose the port for the serial interface.

Start the EKM or change from the design mode to the start window.



## 3.5.1 Reading a key


To read a key, push the key into the EKS Electronic-Key adapter. The read process starts automatically. Progress during the read process is displayed on the status bar in *Key access*.



When the key is read, the data on the key are automatically transferred to EKM server database. Once the read process is complete, the data are displayed on the key form.

Key data		Additional information	
	Key ID 00D45F3365001032	Distributed on	05.01.2004
Locked	<input type="checkbox"/>	Distributed at	10:00:00
User level	8	Distributed to	Tom Miller
User ID	234567	User	
Access	Building1 <input checked="" type="checkbox"/> Building2 <input checked="" type="checkbox"/> Building3 <input type="checkbox"/>	Comment	born in New York 30 years old
Valid until	12.07.2006		

You can also start the read process manually:



click the *Read* button on the toolbar or the *Read* command on the *Edit* menu.

The data displayed on the form are overwritten on renewed reading.

Note that the read process is dependent on the selection of the field property *OnKey*:

**OnKey activated:** On reading the value is read directly from the key, transferred to the database and displayed in the form. If the key does not contain any valid data, you will receive a message and the invalid value will be replaced by a default value.


**OnKey deactivated:** On reading the value is read directly from the database and displayed in the form.

The first time fields are read without *OnKey* selected, the database fields are ZERO. Blank fields are displayed in the form.

## 3.5.2 Writing a key

To write to a key, push the key into the EKS Electronic-Key adapter. First the read process starts automatically. Then enter the data on the form (for information on data entry [cf. "Data entry"](#)).

To start the write process, click




the *Write* button on the toolbar or the *Write* command on the *Edit* menu.

The progress during the write process is displayed on the status bar in Key access.



The data are automatically transferred to the EKM database when the key is written. Once the write process has been completed successfully, a message is displayed:



Accept the message with *OK*.

The key must not be removed during the write process.

The use of duplicates in Unique fields is detected prior to executing the write process: you will receive an error message if you have entered a value that has already been used in a field with the Unique restriction.



The write process is not executed.

### 3.5.2.1 Data entry

Data entry when writing to a key varies depending on the form component.

Key data	Additional information
<b>Key ID</b> <input type="text" value="00D45F3365001032"/>	<b>Distributed on</b> <input type="text" value="05.01.2004"/>
<b>Locked</b> <input type="checkbox"/>	<b>Distributed at</b> <input type="text" value="10:00:00"/>
<b>User level</b> <input type="text" value="2"/>	<b>Distributed to</b> <input type="text" value="Tom Miller"/>
<b>User ID</b> <input type="text" value="234567"/>	<b>User</b> 
<b>Access</b> <input checked="" type="checkbox"/> Building1 <input checked="" type="checkbox"/> Building2 <input type="checkbox"/> Building3	<b>Comment</b> <input type="text" value="born in New York 30 years old"/>
<b>Valid until</b> <input type="text" value="12.07.2006"/>	<b>Production Department</b> <input type="text" value="Production, Maintenance"/>
<b>Visu Access</b> <input type="text" value="4128768"/>	<b>Password</b> <input type="text" value="***"/>
<b>Visu User Level</b> <input type="text" value="Level2: Operate"/>	
<b>User Name</b> <input type="text" value="PM_Miller_Tom"/>	

①

**cxDBTextEdit:** Click the field and enter one line of text.

②


**cxDBMemo:** Click the field and enter several lines of text.

③

**cxDBSpinEdit:** Click one of the arrows. The number is increased or decreased. You can also enter a number directly by clicking the field.

④

**cxDBCheckBox:** Click the check box to set or activate the defined property. A check mark appears in the check box. To deactivate the field, click the activated check box. The check box is now empty.

⑤

**cxDBTimeEdit:** Click one of the arrows. The time is put forward or put back. You can also place the cursor directly in the field and enter a time. The cursor moves forward automatically so that the entry is always in the correct format.

⑥

July							2006	
M	D	M	D	F	S	S		
26	27	28	29	30	1	2		
3	4	5	6	7	8	9		
10	11	12	13	14	15	16		
17	18	19	20	21	22	23		
24	25	26	27	28	29	30		
31	1	2	3	4	5	6		




**cxDBDateEdit:** Click the arrow. A calendar opens. Choose a date by clicking a day directly on the calendar. Click the month bar to choose a different month.

You can page through the calendar using the arrow buttons on the month bar, i.e. move back and forward.

Click the *Today* button to choose today's date.

Click the *Clear* button to remove a selected date.


⑦



**cxDBImage:** Click the form component using the right mouse button. A context menu appears:


- *Cut* removes the image from the form component and saves it to the Windows Clipboard.
- Using *Insert* you can paste an image from the Clipboard into a form component of type *cxDBImage*.
- Using *Copy* you can copy the image from the form component to the Clipboard.
- Using *Delete* you can delete an image from the form component.
- Using *Load* you can open a dialog box for opening a file. Select the image file and accept your selection by clicking the *Open* button.
- You can save an image using *Save As*. The *Save As* window opens first. Select a folder, enter a file name and accept your entries by clicking the *Save* button.

⑧




**cxBitstring:** Click the arrow. A dialog box with check boxes opens containing the bits to be set. Comments related to the bits are displayed. Set the bits in the dialog box by selecting the related check boxes. When you close the dialog box, the bits set are displayed in a corresponding decimal or hexadecimal character string.

⑨



**cxDBExComboBox:** Click the arrow to open the pull-down menu. Select an entry on the pull-down menu. The selected value is not written to the key, instead a value saved in the Layout Designer for this menu entry is written to the key. You cannot enter any text in the field.

⑩



**cxDB\_Combobox:** Click the arrow to open the pull-down menu. Select an entry on the pull-down menu. You can also enter text in the field and transfer the text to the key or to the database using *Write*.

⑪



**cxDBPassword:** Click the field and enter text. The text entry is hidden using the character " \* ". For data security reasons " \*\*\* " is displayed when you leave the field with the cursor.

## 3.5.3 Using templates




Using templates you can save defined values in form fields and use these values as required. Templates can be used to speed up writing similar data to keys.

To create and use templates, proceed as follows:

First create a template:

- Enter the required values on your form. There must be a key in the EKS Electronic-Key adapter to enter data.
- Click *Tools* -> *New template*. Enter a name for the new template in the *Save template* window and accept your entries with *OK*.



All fields that have been enabled in the Database Designer for use in templates are saved in the template with the value entered (cf. "[Properties of the data fields](#)").

The template is a TXT file that is saved on the EKM server.


How to use a template:

- Click *Tools* -> *Template list*. A list is opened with the templates already added. Select the template you want to use.



Once a template has been selected, the *Template* button is available on the toolbar.

- Insert the key you want to write in the EKS Electronic-Key adapter. Click the *Template* button on the toolbar or use the *Template* command on the *Tools* menu. The values saved in the template fields appear on the form.



- If necessary, add data to the form and click *Write* to transfer the data to the key.

### 3.5.4 Discarding changes

If you do not want to save changes to key data, but instead want to discard the changes, click




the *Discard* button on the toolbar or the *Discard* command on the Edit menu.

The data last transferred to the key are displayed on the form.

### 3.6 Database viewer

To open the database viewer, click




the *Database* command on the *Tools* menu or



the *Database* button on the toolbar.

The *Database viewer* window opens




Here you can see all the key data already entered. The data fields written to the key have a yellow background.



### 3.6.1 Working with data

Lists of data records are displayed in tabular form in the EKM. Examples of these data tables are the data views in the *database viewer* and in the Database Designer. The figure below shows all key data already read into the *database viewer*.



KEYID	LOCKED	ValidUntil	DistributedTo	DistributedOn	Distributed
00D45F3365001032	<input type="checkbox"/>	17.01.1900	Taylor Hackford	01.01.2000	10:00:00
00D52A952D001032	<input type="checkbox"/>	31.12.2007	Marry Smith	18.07.2004	11:11:00
00D5F16FDE001032	<input type="checkbox"/>	31.01.2003	Jamie Foxx	05.02.2004	11:03:00
00D6106A47001032	<input type="checkbox"/>	12.07.2006	Tom Miller	05.01.2004	10:00:00
011A0DE432001032	<input type="checkbox"/>	27.04.2006	Regina King	24.08.2002	16:22:00
011A1BF918001032	<input type="checkbox"/>	30.06.2006	Steven Spielberg	01.12.2003	18:00:20
011A28BED8001032	<input type="checkbox"/>	31.12.2006	Tom McGrath	01.01.2003	09:00:00
011A2E416C001032	<input type="checkbox"/>	11.07.2005	Georg Bush	13.11.2001	16:44:00
0132C173C9001032	<input type="checkbox"/>	28.01.2005	Boss Hoss	01.01.2003	08:00:00

Various functions are integrated into the tabular view:


- Searching
- Changing the position of a column
- Sorting by columns
- Grouping by columns
- Filtering data

You can mark a row by clicking the row using the mouse. The functions for changing lists of data described here are not saved when the related data view is closed.


 These functions are not always integrated into every data table in their entirety.


**3.6.2 Changing data in the database viewer**

In the database viewer, you can only change data that are not written to the key. Data fields that are written to the key have a yellow background. To change data, click the data field you want to change. Overwrite the data field with the value that you want to enter in the data field.




Once you have made all the necessary changes, leave the database viewer using **OK**.


 Your changes will be transferred to the EKM server as soon as you leave the modified field in the database viewer with the cursor or close the database viewer.

 The database viewer includes field-specific windows, pull-down menus and pre-formatted fields for entering data (cf. "[Data entry](#)").

3.6.3 Deleting database records in the database viewer


To delete data records in the database viewer, select a data record by clicking it. Then click the *Delete* button.



 A warning message is displayed. Accept the message using Yes if you want to delete the selected data record and the related data. Your changes will now be transferred to the EKM server.

3.6.4 Exporting data


In the database viewer you can export key data.




- During a CSV export all key data with the exception of the Memo, Graphic and StringPassword data types are exported to a CSV file.
- The first row in the export file contains the names of the database fields
- Order of the database fields:
  - Database field KEYID
  - Database field LOCKED
  - Database fields with the key data. The sequence is the same as the order on the key
  - Remaining database fields. The sequence is the same as the order defined in the Database Designer
- During a SmartCard export the serial numbers of the keys (KEYID) are converted to the card code for the SmartCard and saved as file names for zero-byte files.

### 3.6.4.1 CSV export

If you want to save the key data in a CSV file, click the *CSV export* button in the database viewer.



The *Entry of export file* window opens.



Select a folder and enter a file name for the CSV file. Accept using *Open*. After the export a message is displayed:




### 3.6.4.2 SmartCard export


The SmartCard export is used to convert the key serial numbers (KEYID) to the card code for the SmartCard. The card code is saved in the file name for a zero-byte file using the following syntax:

USERMAN\_CARDxxxxxxx.DAT  
 (xxxxxxx stands for the card code).

To export the serial numbers for keys entered as SmartCard card code, click the *SmartCard export* button in the database viewer.




The *Entry of export folder* window opens.





Select a folder and accept your selection using *OK*.


After the export a message is displayed:



In the export folder you will now see the files with the related card codes:



 Locked keys are not saved.


 The key serial number is a sixteen digit hexadecimal number (8 bytes). For the conversion to the card code this number must be converted into an eight digit hexadecimal number (4 bytes):

- The 8 byte key serial number is divided into two 4 byte values.
- The two 4 byte values are added together. Any overflow is ignored. The resulting 4 byte value is the card code.



### 3.6.5 Searching for data


Mark a field in a column with a yellow background in your table overview and type the search term or the character string you want to find. The cursor jumps to the next data record that starts with the character string entered.



The search function is integrated into the database viewer only for the fields with a yellow background. These fields cannot be changed in the database viewer (cf. "[Changing data in the database viewer](#)").

### 3.6.6 Filtering data


When you filter data, you formulate criteria that are used to select the data for the view. To activate the filter selection, click the filter selection for a column. A list of possible selection conditions opens.




If you have selected *Custom* as the criterion, the *Custom Filter* window opens.

Here you can link two conditions using ...

- *and* (both expressions are true)
  - *or* (at least one expression is true)
- A list of operators is available for formulating the specific condition.




Once you have used a filter on a table, the expression appears in the filter status bar.



Here you can open the *Filter builder* window using the *Customize* button.

In this window you can build an expression with as many conditions are required:



You can..


- Select the logical operator for the arguments
- Select the column to which an argument is applied
- Select the condition
- Enter the criterion as required
- Add or remove a single condition or a further group of conditions



Filter expressions can be saved using *Save As* and retrieved using *Open*.


### 3.6.7 Moving columns

To change the position of a column in a table, drag the column to the right or left. Two green arrows will indicate the new position of the column. The column is moved when you release the mouse button.



### 3.6.8 Sorting data

To sort a table based on the content in a column, click the column. The arrow indicates whether the sort order is ascending or descending. The existing sorting is reversed if you click the column again.




You can use several columns for the sorting by holding the Shift key when you click the column headings. If you click a column with the Ctrl key pressed, this column is no longer used for sorting.

### 3.6.9 Grouping data

Grouping the data in a table by a column means that all data records with identical fields in the related column are combined to form a group.

To group by a column, simply drag the column to the grouping bar. You will see this data view:




Groups can be formed based on the content of several columns. The order for forming the groups can be changed in the grouping bar.

To undo a grouping, drag the column back to the column bar.


### 3.7 Importing data

Import...


You can import key data into the key database. The data to be imported must be CSV format. The first row in the CSV file contains the database field names. Only fields that can be unambiguously allocated and that match existing database fields are imported. The file to be imported must contain as a minimum the data field KEYID with values. If database fields are missing during the import, these fields are ZERO after the import.

 To edit the CSV file use an editor that does not change the structure of the file.

To import key data into the key database, click *Import* on the *Tools* menu. The *Database import from CSV file* window opens.




Select the file to be imported and accept using *Open*. The import progress and, on completion of the import, the import logger are displayed in the *Database import from CSV file* window.



Using *Details* you can close or open the import logger.

If the import file contains data records that already exist in the key database, you will receive a message:



Select ...

- *Yes* if you want to overwrite the key data for the KEYID displayed with the data from the import file.
- *No* if the key data for the KEYID displayed are not to be overwritten.
- *Cancel* if you want to cancel the import. The data already imported are retained.
- *Yes to all* if you want to overwrite the key data for all already existing KEYIDs with the data from the import file.

Please note that a data record will be ignored during the import in the following cases:

- The data record contains invalid data. Example:
  - Characters that are not allowed in the related data field
  - Values that are below the minimum or above the maximum for the related data field
- The data record contains a duplicate value for a database field with the Unique restriction.

Using *Tools* -> *Show import log* you can open the import logger for the last import. The log file is saved on the EKM server in the ImportLog folder.

### 3.8 Key export/import

Key Export

Key Import

With the function key export respectively key import the data set of the presently displayed key can be exported respectively imported into an optional folder.

#### **Key export**

In order to export the data set, click in the menu File on the menu command Key export.


The window key export to csv-file opens.

Enter a file name and store the file with Open.

#### **Key import**

In order to import the data set, click in the menu File on the menu command Key import.


The window key import from csv-file opens.



Choose the file to be imported and confirm with Open.



In the window key import from csv-file now the import progress and upon completion of the import the import logger is displayed.



On Details you can close respectively reopen the import logger again.

The read values are displayed on the user interface, but not yet transferred into the data base. Only by using the function Write the imported values will be written on the key and into the data base.


Be aware, that in the following cases a data set is ignored for import:

- The data set contains invalid data, for example:
  - Characters which are prohibited for the respective data field
  - Values which exceed the minimal or maximal size of the respective data field
- The data set contains a duplicate value for a data field with the Unique limitation




- The functions import and export can only be executed when key is plugged.
- The KeyID is not imported.
- Data fields of type Memo, StringPassword and Graphic get not exported.

### 3.9 Design mode



To open the design mode, on the *Tools* menu click *Design mode*. The *Database*, *Layout*, *Cancel*, and *Apply* buttons appear on the toolbar.




In the design mode you can:

- Design the database for the key data
- Design the layout for the key data form
- Transfer all changes to the key data form and all changes to the database to the EKM server using *Apply*
- Discard your changes to the key data form and to the database using *Cancel*

### 3.9.1 Designing a database



To design a database for key data, in the design mode click the *Database* button. The *Database Designer* window opens.



In the Database Designer you can:

- Insert data fields
- Delete data fields
- Change data fields

You can select the buttons in the Database Designer by:

- Clicking the button directly using the mouse or
- Using shortcut keys *Alt+* the underlined letter



The fields with the *OnKey* option are saved on the key.



On leaving the design mode, do not forget to transfer your changes to the EKM server using *Apply* (cf. "[Applying your work in the EKM Designer](#)").

### 3.9.1.1 Properties of the data fields

You can design the database for the key data to suit your requirements using the EKM in the design mode. The only exceptions are the *KEYID* and *LOCKED* data fields that are hard programmed. These fields are added automatically when the database is created. The *KEYID* field can only be read. The *LOCKED* field can only be changed using the database viewer.

Fiel...	On...	Fieldname	Type	StartB...	Length	BitNo	Displa...	Uni...	Templ...
1	<input checked="" type="checkbox"/>	Gultigbis	DateAscii	0	8			<input type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>	ZugangHalle1	Bit			0		<input type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	ZugangHalle2	ShortInt (-128 .. 127)			1		<input type="checkbox"/>	<input checked="" type="checkbox"/>
4	<input checked="" type="checkbox"/>	ZugangHalle3	Byte (0 .. 255)			2		<input type="checkbox"/>	<input type="checkbox"/>
5	<input checked="" type="checkbox"/>	Personalnummer	SmallInt (-32768 .. 32767)					<input type="checkbox"/>	<input type="checkbox"/>
6	<input checked="" type="checkbox"/>	Berechtigungsstufe	Word (0 .. 65535)		4			<input type="checkbox"/>	<input type="checkbox"/>
7	<input checked="" type="checkbox"/>	Berechtigungsstufe	Integer (32 Bit mit Vorzeichen)		1		Dez	<input type="checkbox"/>	<input checked="" type="checkbox"/>
8	<input checked="" type="checkbox"/>	VisuBerechtigung	Float		3		Dez	<input type="checkbox"/>	<input checked="" type="checkbox"/>
9	<input checked="" type="checkbox"/>	VisuUserLevel	String		2			<input type="checkbox"/>	<input checked="" type="checkbox"/>
10	<input checked="" type="checkbox"/>	Benutzername	StringBlankFilled		10			<input type="checkbox"/>	<input type="checkbox"/>
11	<input checked="" type="checkbox"/>	Benutzername	StringPassword		10			<input type="checkbox"/>	<input type="checkbox"/>
12	<input checked="" type="checkbox"/>	NibbleVier	Time		0,5	0	Dez	<input type="checkbox"/>	<input type="checkbox"/>
13	<input checked="" type="checkbox"/>	Werksbereich	TimeAscii		20			<input type="checkbox"/>	<input checked="" type="checkbox"/>
14	<input checked="" type="checkbox"/>	KEYCRC	Date		30	32	Dez	<input type="checkbox"/>	<input type="checkbox"/>
15	<input type="checkbox"/>	Ausgegebenan	DateAscii		11			<input type="checkbox"/>	<input type="checkbox"/>
16	<input type="checkbox"/>	Ausgegebenam	Memo					<input type="checkbox"/>	<input type="checkbox"/>
17	<input type="checkbox"/>	Ausgegebenum	Graphic					<input type="checkbox"/>	<input checked="" type="checkbox"/>
18	<input type="checkbox"/>	Bemerkung	CRC					<input type="checkbox"/>	<input checked="" type="checkbox"/>
19	<input type="checkbox"/>		BitString					<input type="checkbox"/>	<input checked="" type="checkbox"/>
20	<input type="checkbox"/>		Nibble					<input type="checkbox"/>	<input type="checkbox"/>

The database comprises:

- Fields that are written to the key during the write process
- Data that can be retrieved centrally from the database, but not written to the key.



The amount of memory space for the data fields written to the key is limited. Please see the data sheet on the Electronic-Key for information on the amount of memory available on the key used.



Data fields that are not written to the key can be added almost without limitation. However, for fast data transfer, it should be ensured that excessively large image files are not used.

The following data field properties must be defined when designing the database:

**FieldNo** Information on the order in which the fields are displayed in the *database viewer*. A field can be moved up or down in the display order using *Up* and *Down*. The number is changed automatically when a field is moved. The number is automatically incremented when a field is added.


**OnKey**

- Activated: the field data are saved on the key when data are written to the key.
- Deactivated: the field data are not saved on the key when data are written to the key and can only be seen on the data form.

**Fieldname** Name of the data field  
Spaces and special characters cannot be used with the exception on the underscore ("\_").

**Type** Data type  
The data types listed below are available:

Data type	On Key possible	Number of bytes
Bit	X	8 bits = 1 Byte
ShortInt (-128...127 )	X	1 byte
Byte (0...255)	X	1 byte
SmallInt (-32768...32767)	X	2 bytes
Word (0...65535)	X	2 bytes
Integer (32 Bit mit Vorzeichen)	X	4 bytes
Float	X	8 bytes
String	X	Maximum 116 bytes
String		Maximum 250 bytes
StringBlankFilled: string filled with ASCII blanks (= 20hex)	X	Maximum 116 bytes
StringBlankFilled: string filled with ASCII blanks (= 20hex)		Maximum 250 bytes
StringPassword: string hidden with "****" on the display		Maximum 250 bytes
Time	X	8 byte
TimeAscii: ASCII time format Format on key: hhmmss00	X	8 byte
Date	X	8 byte
DateAscii: ASCII date format Format on key: YYYYMMDD	X	8 byte
Memo		
Graphic		
CRC: checksum on key	X	2 bytes
BitString: integer multiple of 1 byte	X	Maximum 8 bytes
Nibble	X	4 Bit

 Fields with the data types CRC, DateAscii or TimeAscii can only be defined as OnKey fields.

- StartByte** Defines the first byte of the data field on the key  
The numbering starts with " 0 "
- Length** Defines the length of the data field in bytes. This length can only be freely defined for the data types BitString and String.
- BitNo** Defines the bit used in the byte
- On a field of the type Bit.
  - On a field of the type CRC here the StartByte is defined.
  - ON fields of the types Nibble: 0 - bit no. 0-3; 4 - bit no. 4-7.
- DisplayType** For the data types Byte, Word, Bitstring and CRC you can choose between decimal and hexadecimal notation for display.
- Template**
- Activated: the field is enabled for integration in a template: The value from the allocated form field is applied when a template is created, i.e. the value is saved in the template.
  - Deactivated: the field is ignored when a template is created.
- The template function cannot be activated for the fields of type Memo, Graphic, CRC and StringPassword.
- Unique**
- Activated: it is not possible to save duplicate or multiple entries in the field. Duplicates will be detected on writing.
  - Deactivated: there is no unique restriction for the field.



### Notes on the data type CRC

The CRC field forms a checksum using a configurable part of the key user data and the serial number. The area of the user data included in the checksum is defined using the **Startbyte** and **Length** fields.

The field CRC can be placed with a freely selectable StartByte on the key in a flexible manner. For the input of the StartByte the field **BitNo** is used.

Example:

Fiel...	On...	Fieldname	Type	StartB...	Length	BitNo	Displa...	Uni...	Templ...
1	<input checked="" type="checkbox"/>	Gueltigbis	DateAscii	0	8			<input type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>	ZugangHalle1	Bit	9		0		<input type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	ZugangHalle2	Bit	9		1		<input type="checkbox"/>	<input checked="" type="checkbox"/>
4	<input checked="" type="checkbox"/>	ZugangHalle3	Bit	9		2		<input type="checkbox"/>	<input type="checkbox"/>
5	<input checked="" type="checkbox"/>	Personalnummer	Integer (32 Bit mit ...	10	4			<input type="checkbox"/>	<input type="checkbox"/>
6	<input checked="" type="checkbox"/>	Berechtigungsstufe	Byte (0 .. 255)	14	1		Dez	<input type="checkbox"/>	<input checked="" type="checkbox"/>
7	<input checked="" type="checkbox"/>	VisuBerechtigung	BitString	15	3		Dez	<input type="checkbox"/>	<input checked="" type="checkbox"/>
8	<input checked="" type="checkbox"/>	VisuUserLevel	String	18	2			<input type="checkbox"/>	<input checked="" type="checkbox"/>
9	<input checked="" type="checkbox"/>	Benutzername	String	20	10			<input type="checkbox"/>	<input type="checkbox"/>
▶ 10	<input checked="" type="checkbox"/>	KEYCRC	CRC	0	45	46	Dez	<input type="checkbox"/>	<input type="checkbox"/>
11	<input type="checkbox"/>	Ausgegebenan	String		11			<input type="checkbox"/>	<input type="checkbox"/>


In the above example the checksum is formed using the key data from byte 0 to byte 44. The CRC field is saved in the bytes no. 46 and 47.

- ⇒ You can only define one field of type CRC per data base design.
- ⇒ The field name is defined fixed as KEYCRC.
- ⇒ Is the StartByte located within the controlled CRC range, an error message occurs.
- ⇒ The checksum is only calculated when writing on the key.

**Notes on the data type BitString**


The *BitString* field contains a defined number of bytes. The field is used in conjunction with the *cxDBBitstring* form component for defining bits. You can save comments on the bits in the Database Designer.

To save comments on the *BitString* field in the Database Designer, place the cursor on a BitString field and click the *BitString editor* button.






The *BitString editor* opens. Enter the comments on the bits in the *Description* field:



Accept your entries with *OK*. During data entry the comments added are displayed in a *cxDBBitstring* form component related to the BitString field:



**3.9.1.2 Order of the bytes on the key**

The data are saved on the key using the following scheme:

Fiel...	On...	Fieldname	Type	Start...	Length	BitNo	Displ...	Uni...	Tem...
1	<input checked="" type="checkbox"/>	F_Word	Word (0 .. 65535)	0	2		Dez	<input type="checkbox"/>	<input type="checkbox"/>
2	<input checked="" type="checkbox"/>	F_integer	Integer (32 Bit ...	2	4			<input type="checkbox"/>	<input type="checkbox"/>
3	<input checked="" type="checkbox"/>	F_float	Float	6	8			<input type="checkbox"/>	<input type="checkbox"/>
4	<input checked="" type="checkbox"/>	F_string	String	14	8			<input type="checkbox"/>	<input type="checkbox"/>
5	<input checked="" type="checkbox"/>	KEYCRC	CRC (byte 114/...	0	114		Hex	<input type="checkbox"/>	<input type="checkbox"/>

KEYID	00D53122BE001032	F_crc	329E
F_word	258	F_float	-0,123456789
F_integer	16909060	F_string	hallo



Serial Number: 00 D5 31 22 BE 00 10 32

hex	Text (ASCII)
02 01 04 03 02 01 5F 63 39 37 DD 9A BF BF 68 61	000000_c97Ÿžç dha
6C 6C 6F 20 20 20 00 00 00 00 00 00 00 00 00 00	llo 0000000000
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00	0000000000000000
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00	0000000000000000
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00	0000000000000000
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00	0000000000000000
00 00 9E 32	00ž2

The little endian format is used for the order of the bytes on the key:

- Word                                    2 bytes  
 Order on key                         Low byte - high byte  
 Example  
 Dec. value                             258  
 -> hex. value                         01 02  
 On key                                    02 01  
                                           LB HB
- Integer                                    4 bytes  
 Order on key                         Low word - High word  
 Example  
 Dec. value                             16909060  
 -> hex. value                         01 02 03 04  
 On key                                    04 03 02 01

- CRC 2 bytes  
 Order on key Low byte - high byte  
 Example  
 Dec. value 12958  
 -> hex. value

32	9E
9E	32
LB	HB
  
- Float 8 bytes  
 A floating number with eight bytes (64 bits) is divided into three fields:

1	11	52
s	e	f


The value v for the number is defined as follows:  
 If  $0 < e < 2041$ ,  $v = -1 s * 2^{(e-1023)} * (1.f)$   
 If  $e = 0$  and  $f > 0$ ,  $v = (-1) s * 2^{(-1022)} * (0.f)$   
 If  $e = 0$  and  $f = 0$ ,  $v = (-1) s * 0$   
 If  $e = 2047$  and  $f = 0$ ,  $v = (-1) s * \text{Inf}$   
 If  $e = 2047$  and  $f > 0$ , v is a NaN value
  
- Date and Time 8 bytes  
 A floating number in accordance with IEEE 754 with eight bytes (64 bits) is divided into three fields. The integer part corresponds to the number of days since 30.12.1899. The fractional part defines the time.
  
- DateAscii 8 bytes  
 Order on key YYYYMMDD  
 Example  
 Date 13 May 2005  
 On key

32	30	30	35	30	35	31	33
----	----	----	----	----	----	----	----
  
- TimeAscii 8 bytes  
 Order on key HHMMss00  
 Example  
 Time 12:35:48  
 On key

31	32	33	35	34	38	30	30
----	----	----	----	----	----	----	----

### 3.9.1.3 Inserting data fields

To insert data fields, click the *Insert* button in the *Database Designer*.




Once you have entered the properties for the new data field and have selected the data type for the field, click *OK* to apply the changes to the database locally. In the layout design mode you can now bind a form field to the new data field (cf. "[Properties of EKM database components](#)").


To transfer your changes to the EKM server, click *Apply* on the toolbar (cf. "[Applying your work in the EKM Designer](#)").

### 3.9.1.4 Deleting data fields

To delete data fields, mark the data field to be deleted in the *Database Designer* and click the *Delete* button.



A warning is displayed first. If you want to delete the data field marked or the marked row in the *Database Designer*, accept the warning with *Yes*. If the deleted data field was bound to form components, these bindings will also be deleted. A message is displayed:



The form fields with a red background must be re-assigned to a data field.

Your changes are initially applied locally.


To transfer the modified database design to the EKM server, you must click *Apply* on the toolbar ([cf. "Applying your work in the EKM Designer"](#)).




Note that on the deletion of a data field, all related data in the database will also be deleted!

### 3.9.1.5 Changing data fields

To change data fields, click the data field in the *Database Designer* and overwrite the property to be changed or select a different property.



If the modified data field was bound to form components, these bindings will be deleted. The following message is displayed:



The form fields with a red background must be re-assigned to a data field.

Your changes are initially applied locally. To transfer the modified database design to the EKM server, you must click *Apply* on the toolbar (cf. "[Applying your work in the EKM Designer](#)").




In some circumstances all database entries in the column modified will be deleted if changes are made to the data fields: this situation will occur if

- The data type is changed

A change of the length of the string is not a change of the data type!


If the string length is reduced, the characters beyond the new length are cut.

If you activate the Unique property for a field and the column contains duplicate entries in the database, you will receive a message on applying the design.




The activation of the Unique property will not be applied. Database entries will not be deleted.

## 3.9.2 Designing the layout



To design the layout for the key data form, in the design mode click the *Layout* button. The *EKM Designer* and *Alignment palette* windows open. These windows are beside and above the EKM main window and can be moved as required.



Using the EKM Designer you can design and change the key data forms by:

- Inserting form components in the key data form
- Assigning properties to form components
- Moving form components
- Aligning form components
- Deleting form components




Make sure that that you enable newly added form components for viewing and editing in the user manager once you have completed your work in the Layout Designer (cf. "[Assigning rights to a group](#)"). On leaving the design mode, do not forget to transfer your changes to the EKM server using *Apply* (cf. "[Applying your work in the EKM Designer](#)").



### 3.9.2.1 An overview of the EKM Designer

You can use the Layout Designer to create and design forms for viewing and changing key data. You can design the layout of key data forms with the aid of three windows:

- EKM (the form window)
- EKM Designer
- Alignment palette




- ① **Edit menu with the commands:**  
*Undo, Redo, Cut, Copy, Insert*  
The menu commands on the *Edit* menu relate to the last action in the layout design, or to marked form components, or form components saved to the Clipboard.
- ② **Toolbar:**  
The layout design is quit using *Apply* and the current form saved temporarily and locally: the client application continues to use the current form. After *Apply* is clicked, the program changes to the first window in the design mode (cf. "[Design mode](#)"). The program continues to use the current form. To transfer the form to the EKM server and finally save it, click the *Apply* button on the toolbar again. Using *Cancel* you can return to the last form design saved.
- ③ **Form area:**  
Area where the form components are inserted and viewed. If no forms have been created, the form area is empty.
- ④ **Marked form components:**  
In the form area you can move and position the components as required, the appearance of the components and other properties such as the binding to a database can be changed in the EKM Designer.



You can also change the size of the main window in the design mode.

## 3.9.2.1.1 EKM Designer



- ① Component bar:  
Choose here the type of form component you want to insert on your form.
- ② Component inspector:  
Displays a list with all the properties for the component currently marked. To edit a property, click the row for the property.
- ③ Status bar:  
Displays the description for the property you are currently editing.

## 3.9.2.1.2 Alignment palette

Use the Alignment palette to align several form components in the form area.



### 3.9.2.2 Form components

Forms for viewing the key data can contain various form components.

The screenshot shows a form divided into two main sections: 'Key data' and 'Additional information'.

**Key data section:**


- Key ID:** 00D45F3365001032
- Locked:**
- User level:** 2
- User ID:** 234567
- Access:** Building1  Building2  Building3
- Valid until:** 12.07.2006
- Visu Access:** 4128768
- Visu User Level:** Level2: Operate
- User Name:** PM\_Miller\_Tom

**Additional information section:**


- Distributed on:** 05.01.2004
- Distributed at:** 10:00:00
- Distributed to:** Tom Miller
- User:** [User photo]
- Comment:** born in New York  
30 years old
- Production Department:** Production, Maintenance
- Password:** \*\*\*\*

The form components are divided into

- EKM database components: form fields containing data and that are bound to the key database and display key-dependent data.














- EKM standard components: form components without a data binding for fixed text, images, borders, etc.







You will find the components on the component bar in the *EKM Designer* on the *EKM Database* and *EKM Standard* tabs.

EKM database components are::

	cxDBTextEdit	Text field: is used for displaying and entering text of limited length.
	cxDBSpinEdit	Spin-edit field: displays integers. The number can be increased or decreased using the arrow buttons.
	cxDBTimeEdit	Time-edit field: is used for displaying and for entering the time.
	cxDBDateEdit	List box with calendar: is used for displaying and for entering the date.
	cxDBCheckBox	Check box: is used for activating and deactivating defined criteria.
	cxDBMemo	Memo field: is used for displaying and entering text of unlimited length.
	cxDBImage	Graphic field: can be bound to database fields of type Graphic. Graphic formats: JPG, JPEG.
	cxDBPassword	Password field: is used for the hidden entry of passwords and is bound to database fields of type StringPassword.
	cxDBBitstring	Bit entry window: is used for setting bits in a defined number of bytes. The display type in the form field and in the database viewer is a character string in hexadecimal or decimal notation.
	cxDB_Combobox	Pull-down menu: is used for the selection of a menu entry. With the selected menu entry a deposited value is written to the database and possibly to the key. The form field can be bound to database fields of the type String.
	cxDBExCombobox	Pull-down menu: is used for the selection of a menu entry. With the selected menu entry a deposited value is written to the database and possibly to the key. The form field can be bound to database fields of the types String, Nibble, Byte and Word. The displayed value and the value of the data can be different.

EKM standard components are:

	cxGroupBox	Group box: is used to visually combine several form fields in a group; the group box features a label that can be assigned in the component inspector. When a group box is moved, all allocated elements are moved as one element.
	Bevel	3D blank field: is used as a fixed structuring element.
	cxLabel	Label: is used for inserting labels.
	cxImage	Image field: is used for inserting graphics; the following formats are accepted: JPG, JPEG, BMP, ICO, EMF, WMF

The list of properties for the currently marked component is displayed in the component inspector.

Properties	
[-] DataBinding	(TcxDBTextEditDataBinding)
DataField	KeyID
Height	21
Hint	Unique identifier
Left	80
Name	edtKeyID
ShowHint	<input checked="" type="checkbox"/>
[+] Style	(TcxEditStyle)
TabOrder	0
Top	39
Width	130
<b>Left</b> Returns/sets the distance between the internal left edge of an object and the left edge of its container.	

In the component inspector you can access the properties for the form components and change the properties. The component properties are displayed in alphabetical order.

All form components have general properties:

- Design of the component (border, background color, font, shading, etc.)
- Internal name for the component
- Position on the form or within a group box
- Size of the form component
- Hint for a form component
- Sequence number for navigation on the form using the Tab key

In addition to these properties, you can make other settings in the component inspector as a function of the form component inserted:


- For EKM database components, a data field must also be selected for the components using *DataBinding* -> *DataField* to bind the component with the database field. When a database component is inserted, there is initially no binding to a data field.
- For the EKM database components *cxDB\_Combobox* and *cxDBExCombobox*, menu entries for display on the pull-down menu can be entered using *Items*. For the component *cxDBExCombobox* a value in the format String, Byte or Word is saved for the menu entry. The menu entries are added after binding to a data field.
- Using the EKM standard components *cxGroupBox* and *cxLabel* you can enter the label text for the components. By default the labels are *cxGroupBox1*, *cxGroupBox2* or *cxLabel1*, *cxLabel2*.
- With the EKM standard component *cxImage* you can also select an image file in one of the formats JPG, JPEG, BMP, ICO, EMF, WMF. By default an image file is not selected.



Note that the properties are grouped in the component inspector. If you want to view a group of properties, click the plus sign in front of the group; if you want to hide a sub-group, click the minus sign in front of the group.

**3.9.2.2.1 General properties**

All components have general properties. You can change these properties in the component inspector by clicking a property field and entering the value required.



The following list contains all the general properties and the valid entries:

① **Internal component name**

<b>Name</b>	<b>Description</b>	<b>Valid values</b>
Name	Defines the internal form field name: pay attention to clear labeling: e.g. PersonnelNumber or cxDBTextEdit3_Name.	All characters except special characters such as ö, ä etc. as well as the hyphen ("-"), forward slash ("/"), backward slash ("\") and space (" ").

## ② Position of the component

Name	Description	Valid values
Left	Defines the position of the left edge of the component in pixels, starting from the left edge of the form or the group box.	Integer
Top	Defines the position of the top edge of the component in pixels, starting from the top edge of the form or the group box.	Integer


## ③ Size of the component

Name	Description	Valid values
Height	Defines the height of the component in pixels	Integer
Width	Defines the width of the component in pixels	Integer



The height can only be entered directly in the Height field for the form components cxDBMemo, cxDBImage, cxGroupBox, Bevel, Image. The height of the other components is automatically adjusted to the font size set (Style -> Font -> Size).

## ④ Design of the component: Style

Name	Description	Valid values
 Style		
BorderColor	Color of the component border	Select a color from the pull-down menu
BorderStyle	Style for the component border: e. g. flat, 3D etc.	Select a style from the pull-down menu
Color	Component background color	Select a color from the pull-down menu

## ④ Design of the component: Font

Name	Description	Valid values
<input type="checkbox"/> Font	Font for the component content	In the Font field you can open a dialog box where you can access the fonts installed in the operating system. The font, its size and color, etc. can be selected in the dialog box.
Charset	Character set that is used as the basis for the component content.	Select a character set from the pull-down menu
Color	Font color	Select a color from the pull-down menu
Height	Scaling value for the font size referred to the screen resolution	Integer
Name	Font	Select a font from the pull-down menu
Pitch	Adjusts the character spacing	
Size	Font size	Select a font size from the pull-down menu

## ④ Design of the component: Font → Style

Name	Description	Valid values
<input type="checkbox"/> Style		
fsBold	Bold font	Activated / deactivated
fsItalic	Italic font	Activated / deactivated
fsStrikeOut	Struck-through font	Activated / deactivated
fsUnderline	Underlined font	Activated / deactivated

## ④ Design of the component

Name	Description	Valid values
Shadow	Shadow: places a shadow behind the component	Activated / deactivated
Transparent Border	Transparent border	Activated / deactivated



## ⑤ Navigation using the Tab key


Name	Description	Valid values
TabOrder	Defines the order in which the cursor moves between the components when the Tab key is used for navigation	Integer

## ⑥ Hint for component

Name	Description	Valid values
Hint	Hint that appears when you move over the component with a key inserted	All characters except special characters
ShowHint	Defines whether the hint is shown	Activated / deactivated

### 3.9.2.2.2 Properties of EKM database components

EKM database components have general properties as well as an allocation to a database field:














## ① Data used for field content

Name	Description	Valid values
DataBinding	Indicates the type of component	
DataField	Indicates the data field that is used to provide the data for the form component	Select a database field from the pull-down menu




The selected form component must match the data type of the database field allocated ([cf. "Properties of the data fields"](#)). Valid bindings between form components and data types for an allocated database field are:

	<b>cxDBTextEdit</b>	Text field: can be bound to database fields of type <i>String</i> ( <i>String</i> , <i>StringBlankFilled</i> ) and number ( <i>SmallInt</i> , <i>ShortInt</i> , <i>Byte Word</i> , <i>Integer</i> , <i>Float</i> ), the <i>KEYCRC</i> field or the hard programmed <i>KEYID</i> field.
	<b>cxDBSpinEdit</b>	Spin-edit field: can only be bound to database fields of type number.
	<b>cxDBTimeEdit</b>	Time-edit field: can only be bound to database fields of type <i>Time</i> and <i>TimeAscii</i>
	<b>cxDBDateEdit</b>	List box with calendar: can only be bound to database fields of type <i>Date</i> and <i>DateAscii</i> .
	<b>cxDBCheckBox</b>	Check box: can be bound to database fields of type <i>Bit</i> and the hard programmed <i>LOCKED</i> field.
	<b>cxDBMemo</b>	Memo field: can be bound to database fields of type <i>Memo</i> .
	<b>cxDBImage</b>	Graphic field: can be bound to database fields of type <i>Graphic</i> . Graphic formats: <i>JPG</i> , <i>JPEG</i> .
	<b>cxDBPassword</b>	Password field: can only be bound to database fields of type <i>StringPassword</i> .
	<b>cxDBBitstring</b>	Bit entry window: can only be bound to database fields of type <i>BitString</i> .
	<b>cxDB_Combobox</b>	Pull-down menu: can only be bound to database fields of type <i>String</i> .
	<b>cxDBExCombobox</b>	Pull-down menu with saved values: can be bound to database fields of type <i>String</i> , <i>Byte</i> and <i>Word</i> . The database field selection is based on the values that are to be saved for the entries visible on the menu: example: menu entry: <i>Level1</i> - value saved: <i>001</i> => Field with data type <i>String</i>


Menu items can be saved for the combo boxes `cxDB_Combobox` and `cxDBExCombobox` using `Items`:

Click the button in the `Items` field after you have bound the combo box to a data field.



A field-specific string list editor opens:


**String list editor: *cxDB\_Combobox***



Using the *Add* button you can add new entries that are to be displayed on the pull-down menu.

To delete entries, click the row to be deleted and click the *Delete* button.

## String list editor: *cxDBExComboBox*




Add a new row per menu item using the *Add* button. In *Description* enter the text that is to be displayed as the menu entry on the pull-down menu. In *Value* enter the value that is to be saved on the selection of the related menu item. Ensure that the data entered under *Value* match the related database field.

To delete entries, click the row to be deleted and click the *Delete* button.

### 3.9.2.2.3 Properties of EKM standard components

EKM standard components feature some of the basic properties and component-specific properties:

- cxGroupBox



#### ① Label

Name	Description	Valid values
Caption	Text that is used to label the group box	All characters including the special characters

Alignment Indicates how the label is aligned on the group box Select an alignment from the pull-down menu

To insert components in a group box, the group box must first be inserted in the form, then form components can be positioned directly in the group box. However, you can also insert the components in the group box using *Cut* and *Insert*. If you move a group box, the form components contained in the group box are also moved.


- cxLabel



#### ① Label

Name	Description	Valid values
Caption	Text used for the label	All characters including the special characters



- Bevel



① **Profil**

Name	Description	Valid values
Shape	Assigns a profile to an empty field	Select a profile from the pull-down menu

- cxImage



## ① Image source

Name	Description
Picture	The picture wizard is displayed. The picture wizard is used to insert and remove images from the <i>cxImage</i> component:

You can perform the following operations in the picture wizard:



Click *Open* to open an image file and to insert it in the image field. You can insert image files with the following formats: JPG, JPEG, BMP, ICO, EMF, WMF.



Using *Save*, you can save an image that you have opened in the picture wizard.



Using *Copy*, you can copy an image that you have opened in the picture wizard to the Clipboard.



Using *Insert* you can insert an image from the Clipboard in the image field.




Using *Remove* you can remove an opened image from the picture wizard. The image is then also removed from the image field.



### 3.9.2.3 Inserting form components

To insert form components, click the required component on the *component bar*. Then click the form in the position where you want to insert the form component.




The form component is inserted in the form with default properties. Change the properties of the new form component in the component inspector. You can also move the form component again if required. The component that was last inserted is at the front.

To insert components in a group box, the group box must first be inserted in the form, then form components can be positioned directly in the group box. However, you can also insert the components in the group box using *Cut* and *Insert*.

**!** Make sure that you enable newly added form components for viewing and editing in the user manager once you have completed your work in the Layout Designer ([cf. "Rights available"](#)).

- ⚠ If you bind an EKM database component to an invalid database field, you will receive a message:




An invalid binding to a database field occurs if the data type for the selected database field does not match the form field. The invalid database binding is deleted.


### 3.9.2.4 Selecting form components

You can see which form component is selected using the black anchor points. There are several ways you can select a component or several components:

- Click the component using the mouse. If you keep the Shift key pressed, you can select several components.



- Keep the Ctrl key pressed and, using the left mouse button, drag an area around the form components you want to mark. Release the mouse button, all components in the area are marked.




If you want to remove a component from the selection, click the component with the Shift key pressed. To clear a selection, click an empty part of the form area.


### 3.9.2.5 Changing form components

When form components are inserted, the components have the default properties. You can change the position and the size of the component using the mouse pointer and keyboard commands. All the properties of a component can be changed in the component inspector:


- Select a component by clicking it. All the properties of the selected component are displayed in the component inspector.
- Change a property by clicking the property field. When the field is clicked it is opened for editing, i.e. it is possible to write to the field.
- Enter the required values in this field.



If you enter invalid values for properties, the changes are not applied (cf. "General properties" ff.). A message is displayed:




- ⚠ If you bind an EKM database component to an invalid database field, you will receive the message:



An invalid binding to a database field occurs if the data type for the selected database field does not match the form field. The invalid database binding is deleted.

### 3.9.2.6 Cutting form components

Select one or several form components:




- On the *Edit* menu click the *Cut* command
- Or pressing *Ctrl + X*

The selection is now on the Clipboard and can be inserted in a different position.

### 3.9.2.7 Copying form components

Select one or several form components:




- On the *Edit* menu click the *Copy* command
- Or press *Ctrl + C*

The copy is now on the Clipboard and can be inserted.

### 3.9.2.8 Inserting a form component

You can insert form components you cut or copied to the Clipboard by:



- Clicking the *Insert* command on the *Edit* menu
- Or pressing *Ctrl + V*

You will see the new component on the form.

- 💡 On insertion the internal component name is changed if a component with the same name already exists on the form.


### 3.9.2.9 Removing form components

Select one or several form components and press the Delete key.

### 3.9.2.10 Moving form components

To move a component, proceed as follows:

- Select a component.
- Drag the component over the form with the mouse button pressed. You will be able to see the new position of the selected component using the black border. The co-ordinates for the new position are also displayed in the hint (yellow field underneath the mouse pointer).
- Release the mouse button when you have reached the desired position.



You can also move one or several marked form components using keyboard commands:


- Select one or several form components
- Press the Ctrl + arrow keys to move the component up, down, to the right or to the left.



If you move a group box, the form components contained in the group box are also moved.

### 3.9.2.11 Aligning form components

Select form components and click an alignment tool on the *Alignment palette*.



The following alignment tools are available:



Aligns the left edges of the form components with the component marked first



Aligns the vertical center line of the form components with the component marked first



Centers the form components horizontally in the form area or in a group box



Evenly spaces the form components horizontally



Aligns the left edges of the form components with the component marked first



Aligns the top edges of the form components with the component marked first



Aligns the horizontal center line of the form components with the component marked first



Centers the form components vertically in the form area or in a group box



Evenly spaces the form components vertically



Aligns the bottom edges of the form components with the component marked first

### 3.9.2.12 Increasing and reducing the size of form components

You can increase or reduce the size of one or several marked form components using keyboard commands:


- Select one or several form components.
- Press Shift + arrow keys to change the size of the component.



The height can only be set for the form components `cxDBMemo`, `cxDBImage`, `cxGroupBox`, `Bevel`, `Image`. The height of the other components is automatically adjusted to the font size set (Style -> Font -> Size).


### 3.9.2.13 Undoing actions on the form design

You can undo the last action in the Layout Designer by



- Clicking the *Undo* command on the *Edit* menu
- Or pressing *Ctrl + Z*

### 3.9.2.14 Redoing actions on the form design



You can repeat the last actions made in the Layout Designer by clicking the *Redo* command on the *Edit* menu.

### 3.9.3 Applying your work in the EKM Designer




Once you have finished designing the database or a form for the key data, click the *Apply* button on the toolbar. EKM changes automatically from the design mode to the read and write mode. You can transfer the form and database design to the EKM server and save them using *Apply*.


If you have changed the form, you must assign the corresponding user rights to the newly added form components. Otherwise it will not be possible to edit the form components and the components will also not be shown. For this reason, when you apply a modified form the following message is displayed:



If you have changed the database design, the data in the database may be deleted in certain circumstances (cf. ["Changing data fields"](#) ). For this reason when you apply a modified database design, the following message is displayed:



If you activate the Unique property for a field and the column contains duplicate entries in the database, you will receive a message on applying the design.





The activation of the Unique property will not be applied. Database entries will not be deleted.

## 3.9.4 Cancelling your work in the EKM Designer



If you want to cancel your work on the database or on a form, click the *Cancel* button on the toolbar.


 Your changes will not be saved and will also not be transferred to the EKM server. For this reason, when you use *Cancel* the following warning is displayed:




Accept using *Yes* if you want to cancel your work in the design mode. EKM automatically changes from the design mode to the read and write mode and loads the last form that was applied.



### 3.10 User rights



To manage users, groups and rights, on the *Tools* menu click the *User* command. The *User manager* window opens.



In the *User manager* window you can:

- View groups, rights available and users
- Edit, add, remove and copy groups
- Allocate rights to the groups, or remove rights from the groups
- Edit, add and remove users
- Allocate users to the groups, or remove users from the groups

By default the Administrators group has the following rights and users:

Group Administrators → Rights:  
Button\_Database\_Edit  
Button\_Database\_Visible  
Button\_Designer  
Button\_Import  
Button\_ImportLog  
Button\_TemplateList  
Button\_TemplateRead  
Button\_TemplateWrite  
Button\_Undo  
Button\_UserManager  
Button\_WriteKey

→ Users: ekm




After installation change the user name and the password for the default administrator ekm. Add new users and new groups as necessary. Add the available rights to the related groups ([cf. "Rights available"](#)).




During this process ensure that a user group has the right to access the user manager (= Button\_UserManager) and note the related user names and passwords to ensure that it is possible to change the access rights and user data.

## 3.10.1 Managing groups

All groups already added are displayed in the user manager in the left window under *Groups*. To display all the rights held by a group, choose *Rights* on the *View* tab. All rights assigned to a group are listed underneath the group name. To display the rights held by a group, click the plus sign in front of the group name. To hide the rights held by a group, click the minus sign in front of the group name. All the rights available can be seen in the window on the right.




To display all the users in a group, choose *User* on the *View* tab. All users belonging to a group are listed underneath the group name. To display the users in a group, click the plus sign in front of the group name. To hide the users in a group, click the minus sign in front of the group name. All the users added can be seen in the window on the right.




### 3.10.1.1 Adding groups

To add a group to the existing groups, click *Add* on the *Group* tab on the menu bar on the left.




The *Edit group* window opens.




Enter the group name and also a description of the group as necessary.

### 3.10.1.2 Editing groups


To edit a group, select a group in the window on the left under *Groups* by clicking it. Click *Edit* on the *Group* tab on the menu bar on the left.



The *Edit group* window opens.



You can change the name and the description of the group. Accept your changes by clicking the *OK* button.


 If you change the name of a group, the existing allocations of rights and users to the group will be deleted. You must again assign rights and users to the group.

### 3.10.1.3 Removing groups

To remove a group, first select the User view. Now mark the related group by clicking the group. Click *Remove* on the *Group* tab on the menu bar on the left.




A window opens where you can accept your selection using *Yes* if you want to delete the group.




### 3.10.1.4 Copying a group


When a group is copied, all the rights assigned and, optionally, all the users assigned to the original group are copied. To copy a group, select the related group by clicking the group. Click *Copy* on the *Group* tab on the menu bar on the left.




The *Edit group* window opens.



Assign a new group name and accept your entries using *OK*. In the next window you can define whether you want to copy to the group all users assigned to the existing group.




Accept the copying of the user allocations using *Yes* or reject the copying of the user allocations using *No*. The group is inserted with all rights and, as required, users and added using the new group name.



## 3.10.2 Managing rights

To display all the rights available, choose *Rights* on the *View* tab. All rights available are displayed in the window on the right under *Rights available*.




### 3.10.2.1 Rights available


In the EKM the following rights can be assigned in the user manager to the groups added:

Button\_Database\_Edit      Permits changes to database data in the database viewer


Button\_Database\_Visible      Permits access to the database viewer




Button\_Designer      Permits access to the Database Designer and Layout Designer with all design features




Button\_Import      Permits the import of key data in CSV format




Button\_ImportLog      Permits access to the log file for the last import




Button\_TemplateList      Permits the selection of a template




Button\_TemplateRead      Permits the use of a template on a key read




Button\_TemplateWrite      Permits the creation of a template



Button\_UserManager      Permits access to the user manager with all features for making changes



Button\_Undo                      Permits changes to key data to be discarded



Button\_WriteKey                Permits writing to keys



In addition to these rights, each form component must be enabled so that it is shown and can be edited:


- Once you have added form components in the design mode, the right *Component\_Name\_Visible* can be assigned for each component in the user manager. With this right user groups can see the from components added in the main window.
- For EKM database components it is also possible to assign the right *Component\_Name\_Edit*. With this right user groups can change the data read from the key in the form component.

### 3.10.2.2 Assigning rights to a group

Select a group by clicking the group in the window on the left.

Click the double arrow pointing to the left to assign all rights available to the selected group


To assign a single right to the selected group, select a right by clicking it in the window on the right. Then click the single arrow pointing to the left or press *Ctrl + A*.






**3.10.2.3 Removing rights from a group**

Select a right from a group by clicking a right in the *Groups* window on the left. Click the arrow that points to the right towards the *Rights available* window or press *Ctrl + R*.




A window opens where you can accept your selection using *Yes* if you want to remove the right from the group.




**3.10.3 Managing users**

To display all the users already added, choose *Users* on the *View* tab. All users already added are displayed in the window on the right under *Users*.




### 3.10.3.1 Adding users

To add a new user, click *Add* on the *User* tab on the menu bar on the left.



The *Edit user* window opens.

A screenshot of the "Edit user" dialog box. It has a blue title bar with a close button. The dialog contains several input fields and buttons. The fields are: "Username:" (empty), "Full name:" (empty), "Password:" (empty), "Verify password:" (empty), "KeyID" (containing "00D45F3365001032"), "Log on with password" (checked), "Log on with key" (unchecked), "Access count:" (0), "Created date:" (26.05.2006), and "Last access:" (empty). The buttons are "OK", "Cancel", and "Detect key".

Complete all fields and accept your entries by clicking the *OK* button.

You can enable the user profile for two different types of logon:

a) Log on with password:

On logon, the user enters his/her user name and password using the keyboard.

b) Log on with key:

On logon the user inserts his/her key in the EKS Electronic-Key adapter.

To activate log on with key, insert the key for the user you are editing in the EKS Electronic-Key adapter. Read the KEYID by clicking the *Detect key* button.

Activate the *Log on with key* check box.

When you save the new user data using *OK*, the KEYID read will be saved in the user's profile.



If both logon types - log on with password and log on with key - are deactivated, the user profile is inactive.

### 3.10.3.2 Editing users

To edit a user, select a user in the window on the right under *Users* by clicking it. Click *Edit* on the *User* tab on the menu bar on the left.



The *Edit user* window opens.

The image shows a dialog box titled 'Edit user' with a blue title bar and a close button (X) in the top right corner. The dialog contains several input fields and buttons. The 'Username' field contains 'Poter'. The 'Full name' field contains 'Schneider'. The 'Password' and 'Verify password' fields contain '\*\*\*\*\*'. The 'KeyID' field is empty. There are three buttons on the right: 'OK', 'Cancel', and 'Detect key'. Below the 'KeyID' field, there are two checkboxes: 'Log on with password' (checked) and 'Log on with key' (unchecked). At the bottom, there are three read-only fields: 'Access count: 4', 'Created date: 06.11.2003', and 'Last access: 16.01.2004'.

Enter your changes and accept them by clicking the *OK* button.

To activate log on with key, insert the key for the user you are editing in the EKS Electronic-Key adapter. Read the KEYID by clicking the *Detect key* button.

Activate the *Log on with key* check box. When you save the new user data using *OK*, the KEYID read will be saved in the user's profile.



If both logon types - log on with password and log on with key - are deactivated, the user profile is inactive.




If the user name is changed, all existing allocations to groups will be deleted. The user must be allocated to a user group again.

### 3.10.3.3 Deleting users

To delete a user, select a user by clicking the user. Click *Delete* on the *User* tab on the menu bar on the left.




A window opens where you can accept your selection using Yes if you want to delete the user.




### 3.10.3.4 Adding users to a group

Select a group by clicking the group in the window on the left. Then select a user by clicking a user in the window on the right. Click the arrow that points to the left towards the *Groups* window or press *Ctrl + A*.




### 3.10.3.5 Removing users from a group


Select a user from a group by clicking a user in the *Groups* window on the left. Click the arrow that points to the right towards the *Users* window or press *Ctrl + R*.



A window opens where you can accept your selection using *Yes* if you want to remove the user from the group.




### 3.10.4 Loggin on and logging off users



To logon a different user without quitting the program, on the *File* menu click the *Logon* command. In the *Logon* window enter the name and the password for the user who wants to logon.




Accept your entries with *OK*. The program will be re-started and the user settings loaded. If logon using key has been activated in your user profile, you can logon by inserting your key in the EKS Electronic-Key adapter. If your user data are incorrect, you will receive a message:




On the second incorrect logon attempt, the program will close automatically.

If you want to logoff, click the *Logoff* command on the File menu.




Accept the logoff process.



The user rights are reset when you logoff. The *Logon* window opens.


### 3.10.5 Changing password

If you want to change your password, on the *File* menu click *Change password*. In the *Password change* window enter your old password and the new password; accept your entries with *OK*.



### 3.11 EKS interface

The EKS Electronic-Key adapter is connected to the computer over a serial port. You can select a port for the device in the program. Select a COM port on the status bar in the main window:



If the selected port is not available or is use by another device, an error message is displayed. In this case select a different COM port.

### 3.12 Server connection

You can change the connection parameters to the EKM server by:

- Deleting the file *ekm.INI* in the program folder. The *Connection parameters EKM-Server* window appears the next time the program is started (cf. "[Installation](#)"). Enter the new connection parameters.
- Opening the file *ekm.INI* and entering the new connection parameters under *Server Address* and *Server Port*

### 3.13 Uninstalling

You can open the uninstall routine *Uninstall EKM* using the Windows Start menu.

# **EKM server**

**Part**






## 4 EKM server

### 4.1 Installation

You can use the EKM server as a service or as an application. The installation and removal of the server vary depending on how the server is used.

#### 4.1.1 Installation as an application

To install the EKM server, add a new folder for the server and copy the file *EKMServer.exe* to the program folder.




Start the application by double-clicking the file *EKMServer.exe*. The EKM server starts automatically. You will see the EKM server icon in the notification area.



Check the configuration of the EKM server in the server configuration wizard (cf. ["Configuration of the server"](#) ).

## 4.1.2 Installation as service


To install the EKM server, add a new folder for the server and copy the file *EKMServer.exe* to the program folder.



Install the service using the following command:

```
absolute path \EKMServer.exe /install
```

On successful installation the following message is displayed:



You will find the EKM server as a service in the operating system in Services. The service starts automatically when the computer is re-started. You will see the EKM server icon in the notification area.




Check the configuration of the EKM server in the server configuration wizard (cf. ["Configuration of the server"](#)).



The EKM server icon in the notification area is not visible in all operating systems. Please use in this case in the Windows start menu the program call *EKM Admin* (cf. ["EKM Admin"](#)) for the configuration of the EKM server.

## 4.1.3 EKM files


All files created from EKM are stored in the EKM installation path.

-  When EKM is installed on Windows 7, Windows Server 2008 or Windows Server 2008 R2 and the installation path is 'C:\Program Files\<EKM>', the operation system redirects user specific files to the VirtualStore. The VirtualStore is located under:  
'C:\Users\<User>\AppData\Local\VirtualStore\Program Files\<EKM>'.

## 4.2 Starting the EKM server

Start the EKM server:


- In your operating system in Services. The EKM server is listed as a service with the name EKM-Server.
- In the server configuration wizard (cf. "[The server configuration wizard](#)"). Click the *Start Server* button.





### 4.3 Stopping the EKM server

Stop the service for the EKM server:


- In Services in the operating system.
- In the server configuration wizard (cf. "[The server configuration wizard](#)" ). Click the *Stop Server* button.



If EKM users are connected to the EKM server, the following messages are displayed. Accept the messages with Yes if you want to stop the EKM server service:



When you exit the EKM server, a warning is displayed to the users:



## 4.4 Uninstalling

You can use the EKM server as a service or as an application. The installation and removal of the server vary depending on how the EKM server is used.

### 4.4.1 Uninstalling the EKM server as application

If you installed the EKM server as an application and started the server, you only need to quit the application to uninstall the EKM server. Click the EKM server icon in the notification area using the right mouse button.



The EKM server context menu opens. Click the *Close* command.




The EKM server icon disappears from the notification area. If you no longer want to use the EKM server, you can delete the program folder containing the file *EKMServer.exe*.

### 4.4.2 Uninstalling the EKM server as service

To uninstall the EKM server service, use the following command:

```
absolute path \EKMServer.exe /uninstall
```

On a successful uninstall the following message is displayed:




The EKM server will no longer be listed in Services in the operating system when the computer is re-started.

## 4.5 The server configuration wizard

Open the configuration wizard by ...




- Double-clicking the EKM server icon in the notification area.



- Opening the context menu by clicking the EKM service icon in the notification area using the right mouse button and clicking the *Properties* command.

The server configuration wizard opens. Click the *Properties* tab and stop the EKM server by clicking the *Stop Server* button.




In the server configuration wizard you can:

- Configure the server
- Set the type of key used
- Display log entries
- Display users logged on

## 4.5.1 Configuration of the server

To configure the EKM server, you must first stop the server. The configuration options are only available after the server has been stopped:



You can see the default settings in the figure. As a rule the options set on installation do not need to be changed. If necessary, the log function can be switched off to improve performance.

### Server Configuration:

- IP Address** IP address used by the EKM server for the communication with the clients.  
 Normally *Automatic* should be entered here. The EKM server can then communicate using all available network cards. If there are several network cards in the machine and communication is only to take place using a specific card, enter the IP address for this network card.
- Port** TCP/IP port
- Autostart** Activated: the EKM server is ready for communication immediately after program start.
- Service-GUI** Activated: the EKM server icon appears in the notification area when the EKM server is installed as a service.

**Database Connection:** Displays the key database folder used.

### Electronic-Key-Type:

- Read/Write** Key type that it is allowed to read and write.
- Read-Only** Key type that can only be read

You can also enter all parameters directly in the configuration file *EKMServer.ini* using a text editor:


```

Section      Configuration entry
[Server]     AutoStart=0|1
             Port==<PortNumber>
             IPAddress=Automatic|<IPAddress>|<ComputerName>
             ShowTrayIcon=1|0
[KeyType]    ReadOnlyKey=1|0
    
```

The server must be stopped to be able to make changes to the configuration. For this purpose click the *Stop Server* button. During this process the connection to all clients is interrupted.

## 4.5.2 Log-Properties

Click the *Log-Properties* tab in the server configuration wizard to define the behavior of the server logger and the key logger.



### Logger (=server logger):

**Write Logfile**      Activated: a log file is written per day. The file name comprises the current date and a file name that can be defined as required:

<YYYY>\_<MM>\_<DD>\_<file name>.txt

Enter a file name and path in *Logfile*. Use the browse button in the *Logfile* field to select a folder.



**Logfile** Path and file name for the log file to which the server logger is to be written.

The default file name is *ekm.txt*. The default folder is the EKM server installation folder.

Example:

Directory: C:\Temp\ekm.txt

Log day: 26 April 2006

The following log file is created in the folder C:\Temp\ for 26 April 2006:  
2006\_04\_24\_ekm.txt

**Delete logfiles after X days** All log files are deleted after X days..

**Online-Logger** Activated: the server logger is displayed on the EKM server in *Logger*.

**Key-Logger (=logger for keys inserted):**

**Write Logfile** Activated: a log file is written per day. The file name comprises the current date and a file name that can be defined as required:

<YYYY>\_<MM>\_<DD>\_<file name>.txt

Enter a file name and path in *Logfile*. Use the browse button in the *Logfile* field to select a folder.

**Logfile** Path and file name for the log file to which the key logger is to be written.

The default file name is *key.txt*. The default folder is the EKM server installation folder.

Example:

Directory: C:\Temp\key.txt

Log day: 26 April 2006


The following log file is created in the folder C:\Temp\ for 26 April 2006:  
2006\_04\_26\_key.txt

**Delete logfiles after X days** All log files are deleted after X days.

**Online-Logger** Activated: the key logger is displayed on the EKM server in *Key-Logger*.

## 4.5.3 Logger

In the server configuration wizard click the *Logger* tab. Log entries on the EKM server are displayed.



The *Online-Logger* option in *Log-Properties: Logger* must be activated to display the log entries in the EKM server window.

The online logger is deleted when the EKM server is re-started. The log entries in the online logger are overwritten after 500 entries.

Example log messages:


Log message	Explanation
Connected...	A client has connected to the EKM server.
Login...	A client is logging onto the EKM server.
Select SQL...	Database query
Update SQL...	Changes to data in the database
Insert SQL...	Insertion of data in the database


#### 4.5.4 Key-Logger


In the server configuration wizard click the *Key-Logger* tab. The Key-Logger records the Key-In and Key-Out events:

- Key-In: A key is inserted in the EKS Electronic-Key adapter
- Key-Out: A key is removed from the EKS Electronic-Key adapter.

Date, time and KEYID are also logged with the events.




 The *Online-Logger* option in *Log-Properties: Key-Logger* must be activated to display the log entries in the EKM server window.

 The online key-logger is deleted when the EKM server is re-started. The log entries in the online key-logger are overwritten after 500 entries.


## 4.5.5 Users logged on

Click the *Users* tab in the server configuration wizard. All clients connected to the EKM server are logged on.



## 4.5.6 Export functions

Click the *Export* tab in the server configuration wizard to define the CSV or SmartCard export functions.



## ① CSV-Export

During a CSV export all key data with the exception of the Memo, Graphic and StringPassword data types are exported. You have two options for the export:

### a) *Start export after any change*

- The key data are exported to a CSV file.
- The first row in the export file contains the names of the database fields
- Order of the database fields:
  - Database field KEYID
  - Database field LOCKED
  - Database fields of the key data. The sequence is the same as the order on the key.
  - Remaining database fields. The sequence is the same as the order defined in the Database Designer


### b) *Start export and external customized conversion program after any change*

- The key data are exported to a temporary CSV file.
- To setup the temporary export file: see *CSV-Export a)*
- After the export to CSV the external program for processing the data from the CSV file is opened.
- A further export can only be triggered if the temporary CSV file has been deleted.
- Example for possible applications:

An application that encrypts key data is used. When opened the application accesses the CSV export file, processes the key data and outputs the encrypted data in another file. Once the process is complete, the CSV export file is deleted by the application.

## ② SmartCard export:

The serial numbers of the keys (KEYID) are converted to the card code for the SmartCard and saved as file names for zero-byte files.



The file names have the following syntax:

USERMAN\_CARDxxxxxxx  
(xxxxxxx stands for the card code).

Locked keys are not saved or deleted.

The key serial number is a sixteen digit hexadecimal number (8 bytes). For the conversion to the card code this number must be converted into an eight digit hexadecimal number (4 bytes):

- The 8 byte key serial number is divided into two 4 byte values.
- The two 4 byte values are added together. Any overflow is ignored. The resulting 4 byte value is the card code.

To activate an export function, proceed as follows:

① CSV export:

a) *Start export after any change*

In the *Export-File* field enter an export file and path. During this process you can use the open or browse dialog box by clicking the button in the *Export-File* field.

Activate the related check box for the export:

CSV - Export

Start export after any change

Start export and external customized conversion program after any change

Export-File:  ...

External-Program:  ...

The CSV export is performed automatically after every change to the key data.

b) *Start export and external customized conversion program after any change*

In the *Export-File* field enter an export file and path. During this process you can use the open or browse dialog box by clicking the button in the *Export-File* field.

In the *External Program* field enter an exe file and path. During this process you can use the open or browse dialog box by clicking the button in the *External-Program* field.

Activate the related check box for the export.

CSV - Export

Start export after any change

Start export and external customized conversion program after any change

Export-File:  ...

External-Program:  ...




After every change to the key data it is checked whether a temporary file exists. If there is no temporary export file, the key data are exported. After the CSV export the defined application is started by the EKM server.

## ② SmartCard export:

Enter an export folder and path in the *Export-Folder* field. During this process you can use the open or browse dialog box by clicking the button in the *Export-Folder* field.

Activate the check box for the export:



The SmartCard export gets initiated, respectively a data synchronisation between EKM database and SmartCard export folder is carried out, when:

- the SmartCard export gets activated in the check box *Start export after any change* when the server is running
- the server gets started and SmartCard export is already activated

After activation of the SmartCard export function in the server, in the configuration file *EKMServer.ini* an entry *[SmartCard-Export]* is automatically generated.

When the server is running, an automatic data synchronisation takes place between EKM database and SmartCard export folder. The default value for the cyclic synchronisation is 24 hours. This value applies without further entry in the configuration file.

Alternatively a time interval for the automatic data synchronisation in deviation to the default value (24 hours) can be set in the configuration file *EKMServer.ini*. For this, add the following configuration entry in the configuration file *EKMServer.ini*:

Section	Configuration entry
[SmartCard-Export]	Check interval=<time in hours>

Valid entries for the time in hours are values in whole numbers 1, 2, 3 through n. For the data synchronisation in a time interval of 2 hours, the configuration entry *Check interval=2* is required for example. For the data synchronisation in a time interval of 2 days, the configuration entry *Check interval=48* is required for example.



The server must be stopped to be able to make changes to the configuration. For this purpose click the *Stop Server* button. During this process the connection to all clients is interrupted.

Changes in the SmartCard export folder are carried out when:

- Key establishing: related SmartCard file is created
- Key deleting: related SmartCard file is deleted

- Key locking: related SmartCard file is deleted
- Key unlocking: related SmartCard file is created

On changes of data which are stored on the key, respectively are assigned to the key via data base, there is no export.

When SmartCard export is activated, the export and synchronisation activities are recorded in the *Logger* (cf. ["Logger"](#)), provided that it is activated in the server.

When the server is stopped or the export gets deactivated in the check box *Start export after any change* when the server is running, then the SmartCard files remain in the SmartCard export folder without change.

## 4.6 Update function

Electronic-Key-Manager EKM features an automatic update function for the EKM client as well as for the EKM online help. For this purpose the folder "ClientVersion" is automatically added to the program path for the EKM server on program start. You can save more recent versions of the EKM client and the EKM online help in this folder.

### 4.6.1 EKM client update


If a new version of the EKM client is available, copy the file *EKM.EXE* to the EKM server's "ClientVersion" folder. To apply the new version, stop and start the EKM server. All EKM clients will receive the new version on the next logon. On the application of the new functions the EKM client is automatically quit and re-started.

### 4.6.2 EKM online help update

If a new version of the EKM online help is available, copy the files *EKM\_D.CHM* und *EKM\_E.CHM* to the EKM server's ClientVersion folder. To apply the new version, stop and start the EKM server. All EKM clients will receive the new version on the next logon.

## 4.7 Data backup

All data that EKM clients edit are saved on the server in *DB* in the EKM server program folder:



The *DB* folder contains the following sub-folders and files:

- ① Backup folder
- ② Layout
- ③ Database files

The database contains:

- All key data
- All user data

The layout for the key data form is saved separately in the file *ekmDesign.dfm*. When a user opens the design mode, a backup copy of the last valid design is saved in the backup folder: The folder containing the backups copies in *Backups* is named using the current date and time. Depending on the changes made in the design mode, database files and / or the file *ekmDesign.dfm* are restored.

 Backup up the folder *DB* at regular intervals.

## 4.8 User-specific logo

The logo displayed in EKM client can be replaced with a user-specific logo. Save the required logo as a file with the name "CompanyLogo.Bmp". Then copy the file to the sub-folder "DB" on the EKM server application path. All EKM clients will receive the user-specific logo the next time they logon. The logo image size is 150 (wide) x 40 (high) pixels.

# **EKM-Admin**


**Part**



## 5 EKM-Admin

EKM admin is used to configure the EKM server. The user interface and functionality are the same as for the EKM server.

EkAdmin.exe und EKMServer.exe are located in the same folder.



To activate the EKM admin, add following entry in the configuration file *EKMServer.ini*:

Section	Configuration entry
[Server]	AdminPort=<port number>

## Index

**- A -**

AdminPort 126  
 Alignment palette 65  
 Automatic update 122

**- B -**

Byte order on key 58

**- C -**

Changing data fields 62  
 Changing key data 34  
 Changing password 103  
 Combo boxes: String list editor 73  
 Combo boxes: items 73  
 Component inspector 67  
 Component properties 67  
 Component properties: EKM database components 73  
 Component properties: EKM standard components 78  
 Component properties: general properties 70

**- D -**

Data backup 123  
 Data table: filtering 41  
 Data table: grouping 45  
 Data table: moving columns 44  
 Data table: searching 41  
 Data table: sorting 44  
 Data transfer to the server 50  
 Data viewer 8  
 database  
   design 15  
 Database Designer 51  
 Database viewer 32  
 Database viewer: data table functions 33  
 default user  
   change 14  
 Deleting data fields 61  
 Deleting key data 35  
 Demo version 9  
 design database 8, 15  
 Design layout 8  
 Design mode 50  
 design user interface 15  
 Design: database 50  
 Design: layout 50

**- E -**

Editing key data 24  
 EKM 7, 8  
 EKM adapter: connecting 24  
 EKM client update 122  
 EKM database components: cxDB\_Combobox 67  
 EKM database components: cxDBBitstring 67  
 EKM database components: cxDBCheckBox 67  
 EKM database components: cxDBDateEdit 67  
 EKM database components: cxDBExComboBox 67  
 EKM database components: cxDBImage 67  
 EKM database components: cxDBMemo 67  
 EKM database components: cxDBPassword 67  
 EKM database components: cxDBSpinEdit 67  
 EKM database components: cxDBTextEdit 67

EKM database components: cxDBTimeEdit 67  
 EKM database components: DataBinding 73  
 EKM database components: DataField 73  
 EKM database components: DataField: valid data types 73  
 EKM Designer 65, 66  
 EKM Designer: alignment palette 66  
 EKM Designer: component bar 66  
 EKM Designer: component inspector 66  
 EKM installation 19  
 EKM online help update 122  
 EKM Server 8  
 EKM server: changing connection parameters 103  
 EKM Server: connection parameters 19  
 EKM server: installation 105  
 EKM server: installation as application 105  
 EKM server: installation as service 106  
 EKM Server: port 19  
 EKM server: starting service 107  
 EKM server: stopping service 108  
 EKM server: uninstalling 109  
 EKM server: uninstalling \: application 109  
 EKM server: uninstalling \: service 109  
 EKM standard components: Alignment 78  
 EKM standard components: Bevel 67  
 EKM standard components: Caption 78  
 EKM standard components: cxGroupBox 67  
 EKM standard components: cxImage 67  
 EKM standard components: cxLabel 67  
 EKM standard components: Picture 78  
 EKM standard components: Shape 78  
 EKM thin client 65  
 EKM: logging off 102  
 EKM: logging on 102  
 EKM: quitting program 21  
 EKM: starting program 20  
 EKM: uninstalling 103  
 EKM-Admin 126  
 EKS 7, 8  
 EKS adapter: interface 103  
 EKS adapter: port 103  
 EKS adapter: selecting port 24  
 Electronic-Key 8  
 Electronic-Key adapter 8  
 Electronic-Key adapter: port 21  
 Entering key data: cxBitstring 27  
 Entering key data: cxDB\_Combobox 27  
 Entering key data: cxDBCheckBox 27  
 Entering key data: cxDBDateEdit 27  
 Entering key data: cxDBExComboBox 27  
 Entering key data: cxDBImage 27  
 Entering key data: cxDBMemo 27  
 Entering key data: cxDBPassword 27  
 Entering key data: cxDBSpinEdit 27  
 Entering key data: cxDBTextEdit 27  
 Entering key data: cxDBTimeEdit 27  
 Export: SmartCard card code 35  
 Export: activating 117  
 Export: configuring export functions 117  
 Export: CSV 35, 36, 117  
 Export: file 117  
 Export: folder 117  
 Export: key data 35, 117  
 Export: Smartcard 38, 117  
 Export: Smartcard card code 117

**- F -**

Form area 21, 65

- Form component 65
- Form components 67
- Form components: aligning 85
- Form components: changing 83
- Form components: copying 84
- Form components: cutting 84
- Form components: increasing size 86
- Form components: inserting 81, 84
- Form components: moving 85
- Form components: reducing size 86
- Form components: removing 85
- Form components: selecting 82
- Full version 10
- G -**
- General properties: Font 70
- General properties: Font: Charset 70
- General properties: Font: Color 70
- General properties: Font: Height 70
- General properties: Font: Name 70
- General properties: Font: Pitch 70
- General properties: Font: Size 70
- General properties: Font: Style: fsBold 70
- General properties: Font: Style: fsItalic 70
- General properties: Font: Style: fsStrikeOut 70
- General properties: Font: Style: fsUnderline 70
- General properties: Height 70
- General properties: Hint 70
- General properties: Left 70
- General properties: Name 70
- General properties: Shadow 70
- General properties: Show Hint 70
- General properties: Style 70
- General properties: Style: BorderColor 70
- General properties: Style: BorderStyle 70
- General properties: Style: Color 70
- General properties: TabOrder 70
- General properties: Top 70
- General properties: TransparentBorder 70
- General properties: Width 70
- H -**
- Help: displaying favorites 23
- Help: opening 23
- Help: searching for topics 23
- I -**
- Import logger 46
- Import: key data 46
- Importing data 46
- Inserting data fields 60
- K -**
- Key access 25, 26
- Key data 8
- Key data: discarding changes 32
- Key database 8, 50
- Key Export 48
- Key Import 48
- Key-In 115
- Key-Logger 115
- Key-Out 115
- L -**
- Language selection 24
- Layout design: applying a form 87
- Layout design: canceling your work 88
- Layout design: redoing an action 86
- Layout design: undoing an action 86
- Layout-Designer: alignment palette 64
- Layout-Designer: EKM Designer 64
- Light version 10
- Little endian format 58
- M -**
- Main window 21
- Managing user rights 89
- Menu bar 21
- Menus 22
- P -**
- Picture dialog 78
- Properties of data fields: BitNo 52
- Properties of data fields: DisplayType 52
- Properties of data fields: Fieldname 52
- Properties of data fields: Length 52
- Properties of data fields: OnKey 52
- Properties of data fields: StartByte 52
- Properties of data fields: Template 52
- Properties of data fields: Type 52
- Properties of data fields: Unique 52
- R -**
- Reading a key 25
- Reading keys 8
- S -**
- Server configuration wizard 110
- Server configuration wizard: Autostart 111
- Server configuration wizard: database connection 111
- Server configuration wizard: electronic-key read only 111
- Server configuration wizard: electronic-key read-write 111
- Server configuration wizard: IP Address 111
- Server configuration wizard: Key-Logger 112
- Server configuration wizard: Key-Type 111
- Server configuration wizard: Logfile 112
- Server configuration wizard: logger 112, 114
- Server configuration wizard: Log-properties 112
- Server configuration wizard: Online-Logger 112
- Server configuration wizard: Port 111
- Server configuration wizard: users logged on 116
- Server status 21
- Single-user version 10
- Status bar 21, 65
- System requirements 9
- T -**
- Template 30
- Template list 30
- Template: creating a template 30
- Template: using a template 30
- Toolbar 21, 22
- U -**
- User database 8
- User display 21
- User groups: adding a group 92
- User groups: copying a group 94
- User groups: editing a group 92
- User groups: removing a group 93
- User groups: Rights view 91
- User groups: Users view 91
- user interface
  - apply 17



- user interface
  - design 15
- User manager 89
- user rights 17
- User rights: assigning right to a group 96
- User rights: Button\_Database\_Edit 95
- User rights: Button\_Database\_Visible 95
- User rights: Button\_Designer 95
- User rights: Button\_ImportLog 95
- User rights: Button\_TemplateList 95
- User rights: Button\_TemplateRead 95
- User rights: Button\_TemplateWrite 95
- User rights: Button\_Undo 95
- User rights: Button\_UserManager 95
- User rights: Button\_WriteKey 95
- User rights: form component display 95
- User rights: form component editing 95
- User rights: removing right from group 97
- User rights: Rights available view 95
- User: adding users 98
- User: adding users to group 100
- User: deleting users 100
- User: editing users 99
- User: removing users from group 101
- Usermanagement 8
- Users: users view 97
- User-specific logo 124

**- W -**

- Writing keys 8
- Writing to a key 26

# EUCHNER

More than safety.

Euchner GmbH + Co. KG  
Kohlhammerstraße 16  
D-70771 Leinfelden-Echterdingen  
info@euchner.de  
www.euchner.com

Edition: 093336-07-10/16  
Title:  
User Manual Electronic-Key-Manager EKM  
Copyright:  
© EUCHNER GmbH + Co. KG

Subject to technical modifications; no responsibility  
is accepted for the accuracy of this information.