



Technische Änderungen vorbehalten, alle Angaben ohne Gewähr / Subject to technical modifications; no responsibility is accepted for the accuracy of this information. © EUCHNER GmbH + Co. KG

X3




markiert Ausrichtung von Pos 1
alignment marking of Pos 1




Z 2 : 1

Z



Pos 3



Pos	Anschlussstyp R Connection type R	
1	-	-
2	-	-
3	X3	M23 Einbaustecker

Bezeichnung Designation	Beschreibung Description	Description
SM	Submodul	Sub module
E_X3	Fehler Zustimmtaster	Error enabling switch
I_X3	Eingang Zustimmtaster	Input enabling switch
I_Tx	Eingang Taster	Input switch
FI_EN	Sicherer Eingang Zustimmtaster	Safety input enabling switch
O_Lx_B	Ausgang Ansteuerung Lx blinken	Output activation Lx to blink
O_Lx	Ausgang Ansteuerung Lx	Output activation Lx

Übersicht der Kommunikationsdaten (Nur bei Systemen mit einem Busmodul MBM):


Overview of the communication data (only for systems with a Bus module MBM):

Geräte definiert mit SW-ID: 137597 in Gerätebeschreibung

Device defined with SW-ID: 137597 in the device description

Input

Ethernet ¹⁾ standard	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1st Byte	-	-	SM_E_X3	-	-	SM_I_T1	SM_I_T2	SM_I_X3
2nd Byte	Diagnose Byte (pluggable)							



Output

Ethernet ¹⁾ standard	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1st Byte	-	-	-	SM_O_L1_B	SM_O_L2_B	-	SM_O_L1	SM_O_L2

¹⁾ Ethernet Protokoll in Abhängigkeit des verwendeten MBM Busmodul / Ethernet protocol according to the used MBM Busmodul